


# E1 Series Servo Drive EtherCAT(CoE) Communications Command Manual



# Revision History

The version of the guide is also indicated on the bottom of the front cover.

MD08UE01-2011\_V1.1



Release Date	Version	Applicable Product	Revision Contents
Nov. 20 <sup>th</sup> .2020	1.1	E1-series CoE drive	<ol style="list-style-type: none"> <li>1. Add a new instruction in 1.3 general precautions: For the instructions of Fieldbus installation and wiring, please refer to "ETG.1600 G (R) V1.0.2" issued by EtherCAT Technology Group.</li> <li>2. Add information in 2.1: After Thunder is installed in a computer with Windows, a user can get the ESI file from the route (C:\HIWIN\doc\CoE).</li> <li>3. Revise table 2.4.1. Move 《Master initializes DC clock synchronization》 from "PreOp to SafeOp" (PS) section to "Init to PreOp" (IP) section.</li> <li>4. Change figure 2.9.1.</li> <li>5. Add 《0x603F Error Code mapping table》 to table 3.2.1.</li> <li>6. Revise below content in 3.2: Change the unit of 0x6071 from "-3000 ~ 3000" to "-32768 ~ 32767". Change the unit of 0x6072 from "0 ~ 3000" to "0 ~ 65535". Change the unit of 0x6077 from "-3000 ~ 3000" to "-32768 ~ 32767". Chang the description of 0x6077 from "The actual torque of the motor. The value is only for referenece." to "The value is given per thousand of rated torque. The value is only for referenece."</li> </ol>
Dec. 04 <sup>th</sup> , 2018	1.0	E1-series CoE drive	First edition.

# Table of Contents

1.	About this Manual .....	1-1
1.1	Preface.....	1-2
1.2	Trademark.....	1-2
1.3	General precautions .....	1-3
1.4	Safety precautions .....	1-4
2.	EtherCAT Communication.....	2-1
2.1	System configuration .....	2-2
2.2	Specifications.....	2-2
2.3	EtherCAT frame structure .....	2-4
2.3.1	EtherCAT commands .....	2-5
2.3.2	WKC (Working Counter) .....	2-6
2.4	EtherCAT State Machine .....	2-7
2.5	Synchronous mode.....	2-10
2.5.1	DC .....	2-10
2.5.2	FreeRun .....	2-11
2.6	SDO abort code .....	2-11
2.7	Emergency message .....	2-12
2.8	PDO (Process Data Object) .....	2-13
2.8.1	PDO mapping object.....	2-13
2.8.2	PDO assign object .....	2-14
2.9	EtherCAT display and setting area .....	2-15
2.9.1	Node address setting .....	2-15
2.9.2	EtherCAT indicators .....	2-16
2.10	EtherCAT related errors .....	2-17
3.	Object Dictionary.....	3-1
3.1	Communication profile area.....	3-2
3.1.1	Default PDO mapping .....	3-7
3.1.2	Mapping objects to PDO .....	3-9
3.1.3	PDO data exchange timing .....	3-11
3.2	Standardized device profile area .....	3-12
3.2.1	PDS (Power Drive System).....	3-21
3.2.2	Profile position mode (pp).....	3-24

## Table of Contents

3.2.3	Cyclic synchronous position mode (csp) .....	3-31
3.2.4	Homing mode (hm) .....	3-33
3.2.5	Profile velocity mode (pv).....	3-38
3.2.6	Cyclic synchronous velocity mode (csv) .....	3-39
3.2.7	Profile torque mode (tq) .....	3-41
3.2.8	Cyclic synchronous torque mode (cst).....	3-43
3.2.9	Touch probe function.....	3-44
3.3	Manufacturer specific profile area .....	3-47
3.3.1	Absolute encoder initialization .....	3-47
3.4	Object dictionary list.....	3-48

# 1. About this Manual

1.	About this Manual .....	1-1
1.1	Preface.....	1-2
1.2	Trademark.....	1-2
1.3	General precautions .....	1-3
1.4	Safety precautions .....	1-4

## 1.1 Preface

This manual introduces EtherCAT (Ethernet for Control Automation Technology) communication and CiA 402 drive profile applied to E1-series CoE (CANopen over EtherCAT) drive. As for basic specifications, wiring and settings of E1-series drive, please refer to “E1 Series Servo Drive User Manual”.

## 1.2 Trademark

EtherCAT<sup>®</sup> is a registered trademark and a patent technology, licensed by Beckhoff Automation GmbH, Germany.





## 1.3 General precautions

This manual is for E1-series CoE drive. Before using the product, please carefully read through this manual. HIWIN Mikrosystem (HIWIN) is not responsible for any damage, accident or injury caused by failure in following the installation instructions and operating instructions stated in this manual.

- Do not disassemble or modify the product. The design of the product has been verified by structural calculation, computer simulation and actual testing. HIWIN is not responsible for any damage, accident or injury caused by disassembly or modification done by users.
- Before installing or using the product, ensure there is no damage on its appearance. If any damage is found after inspection, please contact HIWIN or local distributors.
- Carefully read through the specification noted on product label or technical document. Install the product according to its specification and installation instructions stated in this manual.
- Ensure the product is used with power supply specified on product label or in product requirement. HIWIN is not responsible for any damage, accident or injury caused by incorrect power supply.
- Ensure the product is used with rated load. HIWIN is not responsible for any damage, accident or injury caused by improper usage.
- Do not subject the product to shock. HIWIN is not responsible for any damage, accident or injury caused by improper usage.
- If an error occurs in the drive, please refer to “E1 Series Servo Drive User Manual” and follow the instructions for troubleshooting. After the error is eliminated, power on the drive again.
- Do not repair the product by yourself when it malfunctions. The product can only be repaired by qualified technician from HIWIN.
- For the instructions of Fieldbus installation and wiring, please refer to “ETG.1600 G (R) V1.0.2” issued by “EtherCAT Technology Group”.

## 1.4 Safety precautions

- Carefully read through this manual before installation, transportation, maintenance and examination. Ensure the product is correctly used.
- Carefully read through electromagnetic (EM) information, safety information and related precautions before usage.
- Safety precautions in this manual are classified into “Warning”, “Attention”, “Prohibited” and “Required”.

Signal Word	Description
 <b>Warning</b>	It indicates if the precaution is not observed, it is likely to cause property loss, serious injury or death.
 <b>Attention</b>	It indicates the precaution must be observed.
 <b>Prohibited</b>	It indicates prohibited activity.
 <b>Required</b>	It indicates mandatory activity.





# DANGER


- ◆ Ensure the drive is correctly grounded. Use PE bar in the control cabinet as reference potential. Perform low-ohmic grounding for safety reason.
- ◆ Do not remove motor power cable from the drive when it is still power-on, or there is a risk of electric shock or damage to the contact.
- ◆ Do not touch the live part (contact or bolt) within 5 minutes after disconnecting the drive from power supply. For your own safety, we suggest measuring the voltage in the intermediate circuit and wait until it falls to 40Vdc before touching the live part.




## ■ Operation

 <b>Warning</b>	<ul style="list-style-type: none"> <li>◆ Do not touch the terminals and the internal part of the product when power on, or it may cause electric shock.</li> <li>◆ Do not touch the terminals and internal part of the product within 10 minutes after power off, or the residual voltage may cause electric shock.</li> <li>◆ Do not modify wiring when power on, or it may cause electric shock.</li> <li>◆ Do not damage, apply excessive force to, place any heavy object on the cable or put the cable between two objects, or it may cause electric shock or fire.</li> </ul>
 <b>Attention</b>	<ul style="list-style-type: none"> <li>◆ Do not use the product in location which is subject to humidity, corrosive materials, flammable gas or flammable materials.</li> </ul>


## ■ Storage

 <b>Prohibited</b>	<ul style="list-style-type: none"> <li>◆ Do not store the product in location which is subject to water, water drop, direct sunlight, harmful gas or liquid.</li> </ul>
-----------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------


## ■ Transportation

 <b>Attention</b>	<ul style="list-style-type: none"> <li>◆ Carefully move the product to avoid damage.</li> <li>◆ Do not apply excessive force to the product.</li> <li>◆ Do not stack the products to avoid collapse.</li> </ul>
------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


## ■ Installation site

 <b>Required</b>	<ul style="list-style-type: none"> <li>◆ Do not install the product in location with high ambient temperature and high humidity or location which is subject to dust, iron powder or cutting powder.</li> <li>◆ Install the product in location with ambient temperature stated in the manual. Use cooling fan if the ambient temperature is too high.</li> <li>◆ Do not install the product in location which is subject to direct sunlight.</li> <li>◆ The product is not drip-proof or waterproof, so do not install or operate the product outdoor or in location which is subject to water or liquid.</li> <li>◆ Install the product in location with less vibration.</li> <li>◆ Motor generates heat when running for a period of time. Use cooling fan or disable the motor when it is not in use, so the ambient temperature will not exceed product specification.</li> </ul>
-----------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



## ■ Installation

 <b>Attention</b>	<ul style="list-style-type: none"> <li>◆ Do not place heavy object on the product, or it may cause injury.</li> <li>◆ Prevent any foreign matter from entering the product, or it may cause fire.</li> <li>◆ Install the product in the specified orientation, or it may cause fire.</li> <li>◆ Avoid strong shock to the product, or it may cause malfunction or injury.</li> <li>◆ When installing the product, take the product weight into consideration. Improper installation may cause damage.</li> <li>◆ Install the product on noncombustible objects, such as metal to avoid fire.</li> </ul>
----------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


## ■ Wiring

 <b>Attention</b>	<ul style="list-style-type: none"> <li>◆ Ensure wiring is correctly performed, or it may cause malfunction or burn. There is a risk of injury or fire.</li> </ul>
----------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------

## ■ Operation and transportation

 <b>Attention</b>	<ul style="list-style-type: none"> <li>◆ Use power supply specified in product specification, or it may cause injury or fire.</li> <li>◆ The product may suddenly start to operate after power supply recovers. Please do not get too close to the product.</li> </ul>
 <b>Required</b>	<ul style="list-style-type: none"> <li>◆ Set external wiring for emergency stop to stop the motor at any time.</li> </ul>

## ■ Maintenance

 <b>Prohibited</b>	<ul style="list-style-type: none"> <li>◆ Do not disassemble or modify the product.</li> <li>◆ Do not repair the product by yourself when it malfunctions, please contact HIWIN for help.</li> </ul>
-------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## 2. EtherCAT Communication

2.	EtherCAT Communication.....	2-1
2.1	System configuration .....	2-2
2.2	Specifications.....	2-2
2.3	EtherCAT frame structure .....	2-4
2.3.1	EtherCAT commands .....	2-5
2.3.2	WKC (Working Counter) .....	2-6
2.4	EtherCAT State Machine .....	2-7
2.5	Synchronous mode.....	2-10
2.5.1	DC .....	2-10
2.5.2	FreeRun .....	2-11
2.6	SDO abort code .....	2-11
2.7	Emergency message .....	2-12
2.8	PDO (Process Data Object) .....	2-13
2.8.1	PDO mapping object .....	2-13
2.8.2	PDO assign object .....	2-14
2.9	EtherCAT display and setting area .....	2-15
2.9.1	Node address setting .....	2-15
2.9.2	EtherCAT indicators .....	2-16
2.10	EtherCAT related errors .....	2-17

## 2.1 System configuration

The connection type of EtherCAT is a network system that connects a master and multiple slaves. The number of the connected slaves depends on the factors such as master's performance, communication cycle, etc. The master generates EtherCAT Network Information (ENI) by a configuration tool based on EtherCAT Slave Information (ESI). The ESI file, which provides the peculiar information of the slaves, is an XML-format file given by HIWIN. After Thunder is installed in a computer with Windows, a user can get the ESI file from the route (C:\HIWIN\doc\CoE).

## 2.2 Specifications

Table 2.2.1

Item	Specification
Physical layer	100BASE-TX (IEEE 802.3)
Baud	100Mbps
Connecting cable	Ethernet Category 5 or higher (A twisted-pair cable with double, aluminum tape and braided shielding is recommended.)
Cable length	Maximum 100m between nodes
Connectors	RJ45 x2 CN9 IN: EtherCAT input CN9 OUT: EtherCAT output
EtherCAT indicators	L/A IN x1 L/A OUT x1 RUN x1 ERR x1
Station alias (ID)	Setting 1: 8 bits from 2-digit rotary switch at front panel (Range: 0~255) Setting 2: value saved in EEPROM (Range:0~65535)
Device profile	CoE (CANopen over EtherCAT)
SyncManager	4
FMMU	3
CiA 402 drive profile	Profile position mode Profile velocity mode Profile torque mode Homing mode Cyclic synchronous position mode

	Cyclic synchronous velocity mode Cyclic synchronous torque mode Touch probe function Torque limit function
Synchronous mode	DC Sync0 FreeRun
Cycle time	250, 500, 1000, 2000, 4000 $\mu$ s
Communication object	SDO (service data object) PDO (process data object)
SDO message	SDO request, SDO response, emergency message
PDO mapping	Configurable
Maximum number of PDO mapping objects	RxPDO: 8 TxPDO: 8
Maximum PDO data length	RxPDO: 32 Bytes TxPDO: 32 Bytes

## 2.3 EtherCAT frame structure

EtherCAT frames (Ethernet frames with EtherType 0x88A4, see Figure 2.3.1) are processed by EtherCAT Slave Controller (ESC) on the fly. EtherCAT datagrams are processed before the complete frame is received. If frame checksum is invalid, the slave will set the data invalid for local application.




Figure 2.3.1

## 2.3.1 EtherCAT commands

Table 2.3.1.1

CMD	Abbr.	Name	Description
0	NOP	No operation	Slave ignores command.
1	APRD	Auto increment read	Slave increases address. Slave puts read data into EtherCAT datagram if received address is zero.
2	APWR	Auto increment write	Slave increases address. Slave writes data into memory location if received address is zero.
3	APRW	Auto increment read write	Slave increases address. Slave puts read data into EtherCAT datagram and writes data into the same memory location if received address is zero.
4	FPRD	Configured address read	Slave puts read data into EtherCAT datagram if address matches one of its configured addresses.
5	FPWR	Configured address write	Slave writes data into memory location if address matches one of its configured addresses.
6	FPRW	Configured address read write	Slave puts read data into EtherCAT datagram and writes data into the same memory location if address matches one of its configured addresses.
7	BRD	Broadcast read	All slaves put logical OR of data of memory area and data of EtherCAT datagram into EtherCAT datagram. All slaves increase position field.
8	BWR	Broadcast write	All slaves write data into memory location. All slaves increase position field.
9	BRW	Broadcast read write	All slaves put logical OR of data of memory area and data of EtherCAT datagram into EtherCAT datagram, and write data into memory location. All slaves increase position field. BRW is typically not used.
10	LRD	Logical memory read	Slave puts read data into EtherCAT datagram if received address matches one of the configured FMMU areas for reading.
11	LWR	Logical memory write	Slaves writes data to into memory location if received address matches one of the configured FMMU areas for writing.
12	LRW	Logical memory read write	Slave puts read data into EtherCAT datagram if received address matches one of the configured FMMU areas for reading. Slaves writes data into memory location if received address matches one of the configured FMMU areas for writing.
13	ARMW	Auto increment read multiple write	Slave increases address. Slave puts read data into EtherCAT datagram if received address is zero, otherwise slave writes the data into memory location.
14	FRMW	Configured address read multiple write	Slave puts read data into EtherCAT datagram if address matches one of its configured addresses, otherwise slave writes the data into memory location.

## 2.3.2 WKC (Working Counter)

Working Counter (WKC) is a 16-bit field placed at the end of each EtherCAT datagram. The addressed slave increases WKC based on Table 2.3.2.1 for the master to check if the number of nodes of the corresponding EtherCAT PDU is in line with expectations.

Table 2.3.2.1

Command	Data type	Increment
Read	Fail	0
	Succeed	+1
Write	Fail	0
	Succeed	+1
Read write	Fail	0
	Read succeed	+1
	Write succeed	+2
	Read write succeed	+3



## 2.4 EtherCAT State Machine

EtherCAT State Machine (ESM) is responsible for the coordination of the applications for master and slaves at start up and during operation. State changes are typically initiated by the requests of the master. They are acknowledged by the local application after the associated operations have been executed. Unsolicited state changes of the local application are also possible.

E1-series drive supports the following four states.

- Init
- Pre-Operational
- Safe-Operational
- Operational

The states and the allowed state changes are shown in Figure 2.4.1.




Figure 2.4.1

**Note:** Not all state changes are possible. For example, the transition from 'Init' to 'Operational' requires the following sequence: Init → Pre-Operational → Safe-Operational → Operational.

Table 2.4.1

State / State change	Description
Init	No communication on Application Layer (AL) Master accesses to Data Link (DL)-Information registers
Init to PreOp (IP)	Master configures registers - DL address register - SyncManager channels for Mailbox communication Master initializes DC clock synchronization Master requests 'Pre-Operational' state - Master sets AL Control register Wait for AL Status register confirmation
Pre-Operational (PreOp)	Mailbox communication on AL No Process Data communication
PreOp to SafeOp (PS)	Master configures parameters via Mailbox - e.g., Process Data Mapping Master configures DL Register - SyncManager channels for Process Data communication - FMMU channels Master requests 'Safe-Operational' state Wait for AL Status register confirmation
Safe-Operational (SafeOp)	Mailbox communication on AL Process Data communication (Only Inputs are valid) Drive remains in Safe state (Outputs are blocked)
SafeOp to Op (SO)	Master sends valid Outputs Master requests 'Operational' state (AL Control / Status) Wait for AL Status register confirmation
Operational (Op)	Inputs and Outputs are valid

Table 2.4.2

ESM state	Communication operation		
	send / receive SDO (Mailbox)	TxPDO	RxPDO
Init	-	-	-
PreOp	O	-	-
SafeOp	O	O	-
Op	O	O	O

Table 2.4.3 shows the relationship between PDS (Power Drive System) and ESM states.

Table 2.4.3

PDS \ ESM	Init	PreOp	SafeOp	Op
Not ready to switch on	O	-	-	O
Switch on disabled	O	O	O	O
Ready to switch on	-	O	O	O
Switched on	-	O	O	O
Operation enabled	-	O	O	O
Fault reaction active	O	O	O	O
Fault	O	O	O	O

**Note:**

1. When ESM state receives a transition command from PreOp, SafeOp and Op to Init, PDS state changes to Switched on disabled.
2. When PDS is at Operation enabled state but ESM changes to other states except Op, an error occurs and PDS state changes to Fault.
3. Change of PDS state has no effect on ESM state.

## 2.5 Synchronous mode

There are two types of synchronous mode, DC and FreeRun.

### 2.5.1 DC

The synchronization of EtherCAT communication is based on DC. The local cycle and the servo process of the drive are triggered by Sync0 event.




Figure 2.5.1.1

## 2.5.2 FreeRun

FreeRun is started by the local timer interrupt of the drive. The local cycle runs independently of the communication cycle and the master cycle.




Figure 2.5.2.1

**Note:** The PDO transmission interval should not be less than 250  $\mu$ s.

## 2.6 SDO abort code

When SDO communication error occurs, SDO abort code is returned. The supported SDO abort codes are listed in Table 2.6.1.

Table 2.6.1

Value	Description
06010000h	Unsupported access to an object
06010002h	Attempt to write to a read-only object
06020000h	The object does not exist in the object dictionary
06040042h	Number and length of the objects to be mapped would exceed PDO length
06090030h	Value range of parameter exceeded (only for write access)

## 2.7 Emergency message

When an error occurs, a slave notifies the master of the emergency message through the mailbox communication. An emergency message consists of 8 Bytes of data, as Table 2.7.1 shows.

Table 2.7.1

Byte	0	1	2	3	4	5	6	7
Description	Error code (603Fh) (L)            (H)		Error register (1001h)	Reserved				

The validity or the invalidity of emergency message transmission can be set via 10F3h (diagnosis history).  
The default is validity.

Error code: the same value as 603Fh (error code)

Error register: the same value as the one in 1001h (error register)

## 2.8 PDO (Process Data Object)

The PDOs are used to transfer data during cyclic communication in realtime. RxPDOs receive data from the master. TxPDOs send status from the drive to the master. Objects updated by PDO are not updated by SDO.

### 2.8.1 PDO mapping object

Before using PDO communication, application objects should be mapped to the PDO mapping object. Each PDO mapping object can store up to eight application objects, and the maximum length of the PDO mapping object is 32 Bytes. In the object dictionary, index 1600h to 1603h are for RxPDOs, and index 1A00h to 1A03h are for TxPDOs.

An example of PDO mappings is shown in Figure 2.8.1.1. Three application objects (Obj A, Obj C and Obj F) are mapped to the PDO mapping object 1600h. Please refer to Section 3.1.1 for the default of each PDO mapping object.




Figure 2.8.1.1

## 2.8.2 PDO assign object

Besides PDO mappings described above, it is also necessary to assign PDO mapping table in SyncManager. SyncManager PDO assignment objects describe the relationship between PDO mapping tables and SyncManagers.

In E1-series drive, 1C12h for RxPDO (SyncManager 2) and 1C13h for TxPDO (SyncManager 3) are set to be SyncManager assign objects. The maximum number of mapping objects can be mapped to an assign object is one. Please refer to Section 3.1.2 for the complete procedure of setting PDO mapping.

An example of SyncManager PDO assignment is shown in Figure 2.8.2.1. 1C12h is mapped to the assign object 1600h, which means the first set of the application objects will be used for RxPDO communication.




Figure 2.8.2.1



## 2.9 EtherCAT display and setting area

Figure 2.9.1 shows the EtherCAT display and setting area of E1-series drive.




Figure 2.9.1

### 2.9.1 Node address setting

When communication starts, the master detect the slaves through auto-increment addressing. The slaves are accessed by the master according to the connection order (physical position). That being said, users can define station aliases to enable other network topologies.

The rotary switches are used to set the node address (station alias). The station alias is a unique ID for the master to specify the slave.

#### ■ Station Alias Register (0012h)

The station alias is set in the ESC Configured Station Alias register (0012h) when power supply is on. The value of the register can be read as follows:

Configured station alias = (left set value) × 16 + (right set value)

Table 2.9.1.1

Node address switch setting	Description
00h	The node address is set by the controller.
01h~FFh	The node address switch setting is used as the node address.

**Note: Do not change node address setting after control power-on.**

## 2.9.2 EtherCAT indicators

There are four EtherCAT indicators (LED), RUN, ERR, L/A IN and L/A OUT, on E1-series CoE drive. RUN indicator shows the status of ESM. ERR indicator shows the error status of EtherCAT communication. As for L/A IN and L/A OUT indicator, they shows the physical link states and operation statuses of EtherCAT IN and OUT port. The states of each indicator are described in Table 2.9.2.1.

Table 2.9.2.1

Name	LED color	State	Description
RUN	Green	Off	Init
		Blinking	PreOp
		Single flash	SafeOp
		On	Op
ERR	Red	Off	No error
		Blinking	Communication setting error
		Single flash	Synchronization error
		Double flash	Application watchdog timer (WDT) timeout
		Flickering	Initialization error
L/A IN	Green	Off	Link not established in physical layer
		Flickering	In operation after establishing link
		On	Link established in physical layer
L/A OUT	Green	Off	Link not established in physical layer
		Flickering	In operation after establishing link
		On	Link established in physical layer

The states of the indicators are shown in Figure 2.9.2.1.




Figure 2.9.2.1

## 2.10 EtherCAT related errors

In case of an EtherCAT communication error, the AL status code register (0134h:0135h) will be set. After the error is cleared, the AL status code will also be cleared. The AL status codes of E1-series drive are defined in Table 2.10.1.

Table 2.10.1

Code	Description	Current state / State change	Result state	ERR Indicator
0x0000	No error	Any	Current state	Off
0x0011	Invalid request state change	I→S, I→O, P→O, O→B, S→B, P→B	I + E, P + E, S + E	Blinking
0x0012	Unknown requested state	Any	I + E, P + E, S + E	Blinking
0x0013	Bootstrap not supported	I→B	I + E	Blinking
0x0016	Invalid mailbox configuration	I→P	I + E	Blinking
0x001A	Synchronization error	O, S→O	S + E	Single flash
0x001B	SyncManager watchdog	O, S	S + E	Double flash
0x001D	Invalid output configuration	O, S, P→S	P + E	Blinking
0x001E	Invalid input configuration	O, S, P→S	P + E	Blinking
0x0035	DC invalid sync cycle time	P→S	P + E	Blinking
0x8000	The drive is not in communication mode	Any	Init	Blinking



(This page is intentionally left blank.)



## 3. Object Dictionary

3.	Object Dictionary .....	3-1
3.1	Communication profile area .....	3-2
3.1.1	Default PDO mapping .....	3-7
3.1.2	Mapping objects to PDO .....	3-9
3.1.3	PDO data exchange timing .....	3-11
3.2	Standardized device profile area .....	3-12
3.2.1	PDS (Power Drive System).....	3-21
3.2.2	Profile position mode (pp) .....	3-24
3.2.3	Cyclic synchronous position mode (csp) .....	3-31
3.2.4	Homing mode (hm) .....	3-33
3.2.5	Profile velocity mode (pv).....	3-38
3.2.6	Cyclic synchronous velocity mode (csv) .....	3-39
3.2.7	Profile torque mode (tq) .....	3-41
3.2.8	Cyclic synchronous torque mode (cst).....	3-43
3.2.9	Touch probe function .....	3-44
3.3	Manufacturer specific profile area .....	3-47
3.3.1	Absolute encoder initialization .....	3-47
3.4	Object dictionary list.....	3-48

Every object in the object dictionary is addressed by a 16-bit index and an 8-bit subindex. The standard object dictionary layout is shown in Table 3.1.

Table 3.1

Index	Description
0000h ~ 0FFFh	Data type
1000h ~ 1FFFh	Communication profile area
2000h ~ 5FFFh	Manufacturer specific profile area
6000h ~ 9FFFh	Standardized device profile area
A000h ~ FFFFh	Reserved

## 3.1 Communication profile area

Table 3.1.1

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit							
1000h	00h	Device type	U32	ro	-	0x00020192	-							
		The object displays device type and functionality. The value of a servo drive is 0x00020192.												
1001h	00h	Error register	U8	ro	-	0x0 ~ 0xFF	-							
		The error status of the drive. The value of this object is a part of an emergency message.												
		<table><tr><th>Bit</th><th>Descritption</th></tr><tr><td>0</td><td>Generic error 0: no error; 1: error</td></tr><tr><td>1~7</td><td>Always 0</td></tr></table>		Bit	Descritption	0	Generic error 0: no error; 1: error	1~7	Always 0					
		Bit	Descritption											
0	Generic error 0: no error; 1: error													
1~7	Always 0													
1010h	-	Store parameters	-	-	-	-	-							
		Save the parameter setting in non-volatile memory												
	00h	Number of entries	U8	ro	-	1	-							
	01h	Save all parameters	U32	rw	-	0x0 ~ 0xFFFFFFFF	-							
Write 0x65766173 ("save") to save parameter setting in non-volatile memory. The saving process may take up to 10 seconds. If the object is read during parameter saving process, 0 will be returned. Otherwise, 1 will be returned. During parameter saving process, other SDO commands will be ignored.														
1018h	-	Identity object	-	-	-	-	-							
		Display device information												
	00h	Number of entries	U8	ro	-	4	-							
	01h	Vendor ID	U32	ro	-	0xAAAA	-							
		EtherCAT vendor ID. The value is 0xAAAA.												
	02h	Product code	U32	ro	-	0x05	-							
		The product code of E1-series drive is 0x05.												
	03h	Revision number	U32	ro	-	0 ~ 4294967295	-							
04h	Serial number	U32	ro	-	0 ~ 4294967295	-								
10F1h	-	Error settings	-	-	-	-	-							
		Error setting for Sync error												
	00h	Number of entries	U8	ro	-	1	-							



	02h	Sync error counter limit	U16	rw	-	0 ~ 15	-																									
		It is the process data reception failure threshold. If the value of the internal error counter in the drive exceeds the threshold, the drive will issue an error (AL status code 0x1A) and ESM state will change to SafeOp. The drive increases sync error counter by 3 in case of a missed a SM2 event, while it decreases sync error counter by 1 in case of a received SM2 event. An example of sync error counter is shown as follows.																														
		<table><tr><td>SM2 event</td><td>1</td><td>0</td><td>1</td><td>0</td><td>1</td><td>0</td><td>1</td><td>0</td><td>1</td><td>0</td><td>1</td></tr><tr><td>Sync error counter (Error counter limit = 9)</td><td>0</td><td>3</td><td>2</td><td>5</td><td>4</td><td>7</td><td>6</td><td>9</td><td>9</td><td>9</td><td>9</td></tr></table>							SM2 event	1	0	1	0	1	0	1	0	1	0	1	Sync error counter (Error counter limit = 9)	0	3	2	5	4	7	6	9	9	9	9
		SM2 event	1	0	1	0	1	0	1	0	1	0	1																			
Sync error counter (Error counter limit = 9)	0	3	2	5	4	7	6	9	9	9	9																					
If sync error counter limit is set to 0, the drive will not detect any missing SM2 event.																																
1600h	-	1 <sup>st</sup> RxPDO mapping	-	-	-	-	-																									
	They are the mapping parameters of PDOs that the drive can receive. The value of the object can only be changed when ESM state is PreOp. If subindex 00h is not cleared as 0, subindex 01h to 08h cannot be changed.																															
	00h	Number of entries	U8	rw	-	0 ~ 8	-																									
	01h	Mapping entry 1	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
		It is the 1 <sup>st</sup> RxPDO object to be mapped. The content is defined as below.																														
		<table><tr><td>Bit</td><td>31</td><td>...</td><td>16</td><td>15</td><td>...</td><td>08</td><td>07</td><td>...</td><td>01</td></tr><tr><td></td><td colspan="3">Index number</td><td colspan="3">Subindex number</td><td colspan="3">Bit length</td></tr></table>							Bit	31	...	16	15	...	08	07	...	01		Index number			Subindex number			Bit length						
		Bit	31	...	16	15	...	08	07	...	01																					
		Index number			Subindex number			Bit length																								
	The same setting method applies to the rest of the mapping entries. <b>Note: Mapping the same object to different mapping entries is not supported by the drive.</b>																															
	02h	Mapping entry 2	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	03h	Mapping entry 3	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	04h	Mapping entry 4	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	05h	Mapping entry 5	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	06h	Mapping entry 6	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
07h	Mapping entry 7	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																										
08h	Mapping entry 8	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																										
1601h	-	2 <sup>nd</sup> RxPDO mapping	-	-	-	-	-																									
	The specification is the same as that of 1 <sup>st</sup> RxPDO mapping object.																															
	00h	Number of entries	U8	rw	-	0 ~ 8	-																									
	01h	Mapping entry 1	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	02h	Mapping entry 2	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	03h	Mapping entry 3	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	04h	Mapping entry 4	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	05h	Mapping entry 5	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	06h	Mapping entry 6	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	07h	Mapping entry 7	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
08h	Mapping entry 8	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																										
1602h	-	3 <sup>rd</sup> RxPDO mapping	-	-	-	-	-																									
	The specification is the same as that of 1 <sup>st</sup> RxPDO mapping object.																															
	00h	Number of entries	U8	rw	-	0 ~ 8	-																									
	01h	Mapping entry 1	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	02h	Mapping entry 2	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	03h	Mapping entry 3	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	04h	Mapping entry 4	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	05h	Mapping entry 5	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	06h	Mapping entry 6	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
	07h	Mapping entry 7	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																									
08h	Mapping entry 8	U32	rw	-	0x0 ~ 0xFFFFFFFF	-																										

1603h	-	4 <sup>th</sup> RxPDO mapping	-	-	-	-	-				
	-	The specification is the same as that of 1 <sup>st</sup> RxPDO mapping object.									
	00h	Number of entries	U8	rw	-	0 ~ 8	-				
	01h	Mapping entry 1	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	02h	Mapping entry 2	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	03h	Mapping entry 3	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	04h	Mapping entry 4	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	05h	Mapping entry 5	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	06h	Mapping entry 6	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	07h	Mapping entry 7	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
08h	Mapping entry 8	U32	rw	-	0x0 ~ 0xFFFFFFFF	-					
1A00h	-	1 <sup>st</sup> TxPDO mapping	-	-	-	-	-				
	-	They are the mapping parameters of PDOs that the drive can transmit. The value of the object can only be changed when ESM state is PreOp. If subindex 00h is not cleared as 0, subindex 01h to 08h cannot be changed.									
	00h	Number of entries	U8	rw	-	0 ~ 8	-				
	01h	Mapping entry 1	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
		It is the 1 <sup>st</sup> TxPDO object to be mapped. The content is defined as below.									
		Bit	31	...	16	15	...	08	07	...	01
			Index number			Subindex number			Bit length		
	The same setting method applies to the rest of the mapping entries.										
	<b>Note: Mapping the same object to different mapping entries is not supported by the drive.</b>										
	02h	Mapping entry 2	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	03h	Mapping entry 3	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	04h	Mapping entry 4	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	05h	Mapping entry 5	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	06h	Mapping entry 6	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
07h	Mapping entry 7	U32	rw	-	0x0 ~ 0xFFFFFFFF	-					
08h	Mapping entry 8	U32	rw	-	0x0 ~ 0xFFFFFFFF	-					
1A01h	-	2 <sup>nd</sup> TxPDO mapping	-	-	-	-	-				
	-	The specification is the same as that of 1 <sup>st</sup> TxPDO mapping object.									
	00h	Number of entries	U8	rw	-	0 ~ 8	-				
	01h	Mapping entry 1	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	02h	Mapping entry 2	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	03h	Mapping entry 3	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	04h	Mapping entry 4	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	05h	Mapping entry 5	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	06h	Mapping entry 6	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	07h	Mapping entry 7	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	08h	Mapping entry 8	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
1A02h	-	3 <sup>rd</sup> TxPDO mapping	-	-	-	-	-				
	-	The specification is the same as that of 1 <sup>st</sup> TxPDO mapping object.									
	00h	Number of entries	U8	rw	-	0 ~ 8	-				
	01h	Mapping entry 1	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	02h	Mapping entry 2	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	03h	Mapping entry 3	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	04h	Mapping entry 4	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	05h	Mapping entry 5	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				
	06h	Mapping entry 6	U32	rw	-	0x0 ~ 0xFFFFFFFF	-				

	07h	Mapping entry 7	U32	rw	-	0x0 ~ 0xFFFFFFFF	-
	08h	Mapping entry 8	U32	rw	-	0x0 ~ 0xFFFFFFFF	-
1A03h	-	4 <sup>th</sup> TxPDO mapping	-	-	-	-	-
		The specification is the same as that of 1 <sup>st</sup> TxPDO mapping object.					
	00h	Number of entries	U8	rw	-	0 ~ 8	-
	01h	Mapping entry 1	U32	rw	-	0x0 ~ 0xFFFFFFFF	-
	02h	Mapping entry 2	U32	rw	-	0x0 ~ 0xFFFFFFFF	-
	03h	Mapping entry 3	U32	rw	-	0x0 ~ 0xFFFFFFFF	-
	04h	Mapping entry 4	U32	rw	-	0x0 ~ 0xFFFFFFFF	-
	05h	Mapping entry 5	U32	rw	-	0x0 ~ 0xFFFFFFFF	-
	06h	Mapping entry 6	U32	rw	-	0x0 ~ 0xFFFFFFFF	-
	07h	Mapping entry 7	U32	rw	-	0x0 ~ 0xFFFFFFFF	-
	08h	Mapping entry 8	U32	rw	-	0x0 ~ 0xFFFFFFFF	-
1C00h	-	SyncManager communication type	-	-	-	-	-
		Set the communication type of each SyncManager (SM).					
	00h	Number of entries	U8	ro	-	4	-
	01h	Communication type SyncManager 0	U8	ro	-	1	-
		SM0 is responsible for receiving data through Mailbox. The value is 1.					
	02h	Communication type SyncManager 1	U8	ro	-	2	-
		SM1 is responsible for sending data through Mailbox. The value is 2.					
	03h	Communication type SyncManager 2	U8	ro	-	3	-
		SM2 is responsible for process data output (RxPDO). The value is 3.					
	04h	Communication type SyncManager 3	U8	ro	-	4	-
SM3 is responsible for process data input (TxPDO). The value is 4.							
1C12h	-	SyncManager 2 PDO assignment	-	-	-	-	-
		It is the PDO mapping object entry for SM2, which is responsible for process data output (RxPDO). The value of the object can only be changed when ESM state is PreOp. If subindex 00h is not cleared as 0, subindex 01h to 08h cannot be changed.					
	00h	Number of assigned PDOs	U8	rw	-	0 ~ 1	-
	01h	Index of assigned RxPDO 1	U16	rw	-	1600h ~ 1603h	-
RxPDO mapping object index							
1C13h	-	SyncManager 3 PDO assignment	-	-	-	-	-
		It is the PDO mapping object entry for SM3, which responsible is for process data input (TxPDO). The value of the object can only be changed when ESM state is PreOp. If subindex 00h is not cleared as 0, subindex 01h to 08h cannot be changed.					
	00h	Number of assigned PDOs	U8	rw	-	0 ~ 1	-
	01h	Index of assigned TxPDO 1	U16	rw	-	1A00h ~ 1A03h	-
		TxPDO mapping object index					
1C32h	-	SyncManager 2 synchronization	-	-	-	-	-
	00h	Number of synchronization parameters	U8	ro	-	12	-
	01h	Synchronization type	U16	ro	-	0 ~ 2	-
		Mode of SM2 synchronization 0: FreeRun (not synchronized) 2: DC Sync0 (synchronized with Sync0 event)					
		02h	Cycle time	U32	ro	-	250000 ~ 4000000
	It is the communication cycle of SM. The value is defined as below.						
	Sync mode		Description				
	FreeRun	The local cycle time of the application controller					
	DC Sync0	Sync0 cycle time (09A0h~09A3h)					

	04h	Synchronization types supported	U16	ro	-	5	-	
		The bits corresponding to the supported synchronization modes are set to 1. The meaing of each bit is defined as below.						
		Bit	Description					
		0	FreeRun	The bit is 1.				
		1	SM synchronous mode	The bit is 0.				
		2~4	DC synchronous mode	001b: DC Sync0 event supported				
		5~6	output shift support	00b: not supported				
	7~15	reserved						
	05h	Minimum cycle time	U32	ro	-	187500	ns	
		Minimum cycle time supported by slaves						
	06h	Calc and copy time	U32	ro	-	31250	ns	
		Minimum time for outputs to sync event. Used in DC mode						
	09h	Delay time	U32	ro	-	31250	ns	
		Hardware delay time of the slaves						
	0Ch	Cycle time too small	U16	ro	-	0	-	
		This error counter increases when the cycle time is too small. Therefore, local cycle cannot be completed and input data cannot be provided before the next SM event. Used in DC Mode.						
	1C33h	-	SyncManager 3 synchronization	-	-	-	-	-
		00h	Number of synchronization parameters	U8	ro	-	10	-
01h		Synchronization type	U16	ro	-	0 ~ 2	-	
		Mode of SM3 synchronization 0: FreeRun (not synchronized) 2: DC Sync0 (synchronized with Sync0 event)						
02h		Cycle time	U32	ro	-	250000 ~ 4000000	ns	
		the same as 1C32:02h						
04h		Synchronization types supported	U16	ro	-	5	-	
		the same as 1C32:04h						
05h		Minimum cycle time	U32	ro	-	187500	ns	
		the same as 1C32:05h						
06h		Calc and copy time	U32	ro	-	31250	ns	
		Minimum time for Inputs after Input Latch						
09h		Delay time	U32	ro	-	-	ns	
		the same as 1C32:09h						
0Ch		Cycle time too small	U16	ro	-	0	-	
		the same as 1C32:0Ch						

### 3.1.1 Default PDO mapping

The definition of the default PDO mapping in E1-series drive is described as below.

#### ■ PDO mapping 1 (csp, touch probe, torque limit)

Table 3.1.1.1

	Subindex	Value	Name
RxPDO (1600h)	01h	60400010h	Controlword
	02h	60600008h	Modes of operation
	03h	60720010h	Max torque
	04h	607A0020h	Target position
	05h	60B80010h	Touch probe function
	06h	60FE0120h	Digital outputs: physical output
TxPDO (1A00h)	01h	603F0010h	Error code
	02h	60410010h	Statusword
	03h	60610008h	Modes of operation display
	04h	60640020h	Position actual value
	05h	60B90010h	Touch probe status
	06h	60BA0020h	Touch probe 1 positive edge
	07h	60F40020h	Following error actual value
	08h	60FD0020h	Digital inputs

#### ■ PDO mapping 2 (csv)

Table 3.1.1.2

	Subindex	Value	Name
RxPDO (1601h)	01h	60400010h	Controlword
	02h	60600008h	Modes of operation
	03h	60FF0020h	Target velocity
	04h	60FE0120h	Digital outputs: physical output
TxPDO (1A01h)	01h	603F0010h	Error code
	02h	60410010h	Statusword
	03h	60610008h	Modes of operation display
	04h	60640020h	Position actual value
	05h	606C0020h	Velocity actual value
	06h	60770010h	Torque actual value
	07h	60FD0020h	Digital inputs

## ■ PDO mapping 3 (cst)

Table 3.1.1.3

	Subindex	Value	Name
RxPDO (1602h)	01h	60400010h	Controlword
	02h	60600008h	Modes of operation
	03h	60710010h	Target torque
	04h	60FE0120h	Digital outputs: physical output
TxPDO (1A02h)	01h	603F0010h	Error code
	02h	60410010h	Statusword
	03h	60610008h	Modes of operation display
	04h	60640020h	Position actual value
	05h	606C0020h	Velocity actual value
	06h	60770010h	Torque actual value
	07h	60FD0020h	Digital inputs

## ■ PDO mapping 4 (position, velocity, torque, torque limit, touch probe)

Table 3.1.1.4

	Subindex	Value	Name
RxPDO (1603h)	01h	60400010h	Controlword
	02h	60600008h	Modes of operation
	03h	60710010h	Target torque
	04h	60720010h	Max torque
	05h	607A0020h	Target position
	06h	60B80010h	Touch probe function
	07h	60FF0020h	Target velocity
	08h	60FE0120h	Digital outputs: physical output
TxPDO (1A03h)	01h	60410010h	Statusword
	02h	60610008h	Modes of operation display
	03h	60640020h	Position actual value
	04h	606C0020h	Velocity actual value
	05h	60770010h	Torque actual value
	06h	60B90010h	Touch probe status
	07h	60BA0020h	Touch probe 1 positive edge
	08h	60FD0020h	Digital inputs

### 3.1.2 Mapping objects to PDO

The procedure of setting PDO mapping is described as follows.

- Step 1. Set ESM state to PreOp.
- Step 2. Disable PDO mapping assignment. Set subindex 00h of object 1C12h and 1C13h to 0.
- Step 3. Set the number of mapping entries for PDO mapping object 1600h~1603h and 1A00h~1A03h to 0.
- Step 4. Set all of the mapping entries for PDO mapping object 1600h~1603h and 1A00h~1A03h.
- Step 5. Set the assigned PDO mapping object. Set subindex 1 of object 1C12h and 1C13h.
- Step 6. Enable PDO mapping assignment. Set subindex 0 of object 1C12h and 1C13h to 1.
- Step 7. Set ESM state from PreOp to SafeOp. TxPDO will be effective.
- Step 8. Set ESM state from SafeOp to Op. RxPDO will be effective.

**Note:**

1. The PDO mapping settings will be checked after Step 6. If the mapped objects exceeds the maximum number of PDO mapping objects or maximum PDO data length, SDO abort code 0x06040042 will be returned.
2. It is not allowed to write PDO mapping object in SafeOp or Op state. Otherwise, SDO abort code 0x06010002 will be returned.
3. If unsupported object is written to PDO mapping object, SDO abort code 0x06020000 will be returned.

An example of adding object 607Fh to 1600h and using 1600h as the assigned RxPDO is explained as follows.

## Before change (default setting)

Table 3.1.2.1

	Subindex	Value	Name
RxPDO (1600h)	01h	60400010h	Controlword
	02h	60600008h	Modes of operation
	03h	60720010h	Max torque
	04h	607A0020h	Target position
	05h	60B80010h	Touch probe function
	06h	60FE0120h	Digital outputs: physical output

## After change

Table 3.1.2.2

	Subindex	Value	Name
RxPDO (1600h)	01h	60400010h	Controlword
	02h	60600008h	Modes of operation
	03h	60720010h	Max torque
	04h	607A0020h	Target position
	05h	60B80010h	Touch probe function
	06h	60FE0120h	Digital outputs: physical output
	07h	607F0020h	Max profile velocity

- Step 1. Set ESM state to PreOp.
- Step 2. Disable PDO mapping assignment. Set 1C12:00h to 0.
- Step 3. Set 1600:00h to 0.
- Step 4. Set the value of 1600:07h to 607F0020h. Then, set 1600:00h to 7.
- Step 5. Set the value of 1C12:01h to 1600h.
- Step 6. Set 1C12:00h to 1 to enable PDO mapping assignment.
- Step 7. Set ESM state from PreOp to SafeOp. TxPDO will be effective.
- Step 8. Set ESM state from SafeOp to Op. RxPDO will be effective.



### 3.1.3 PDO data exchange timing

Figure 3.1.3.1 shows an example of PDO exchange between the master and the slaves in DC synchronous mode.




Figure 3.1.3.1

Figure 3.1.3.2 shows an example of PDO exchange between the master and the slaves in FreeRun (DC unused) mode.




Figure 3.1.3.2

## 3.2 Standardized device profile area

Table 3.2.1

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
603Fh	00h	Error code	U16	ro	Y	0x0 ~ 0xFFFF	-
		Display the last error that occurs. The value of the error code is FF**h, where ** is the error code from E1-series drive. Take FF10h as an example. 10h = 16d → Error 16 occurs.					
		<b>0x603F Error Code mapping table</b>					
		<b>0x603F Error Code (hex)</b>	<b>Alarm No.</b>	<b>Alarm Name</b>			
		FF01	AL020	Parameter checksum error			
		FF02	AL021	Parameter format error			
		FF03	AL022	System checksum error			
		FF04	AL024	System alarm 1			
		FF05	AL025	System alarm 2			
		FF06	AL030	Main circuit detector error			
		FF07	AL040	Parameter setting error			
		FF08	AL041	Encoder output pulse setting error			
		FF09	AL042	Parameter combination error			
		FF0A	AL044	Semi-closed/Fully-closed loop control			
		FF0B	AL050	Combination error			
		FF0C	AL070	Motor type change detected			
		FF0D	AL080	Linear encoder pitch setting error			
		FF0E	AL0b0	Invalid Servo ON command alarm			
		FF0F	AL100	Over current detected			
		FF10	AL320	Regenerative overload			
		FF11	AL400	Over voltage			
		FF12	AL410	Under voltage			
		FF13	AL510	Over speed			
		FF14	AL511	Encoder output pulse overspeed			
		FF15	AL520	Vibration alarm			
		FF16	AL521	Autotuning Alarm			
		FF17	AL550	Maximum speed setting error			
		FF18	AL710	Instantaneous overload			
		FF19	AL720	Continuous overload			
		FF1A	AL730	Dynamic brake Error			
		FF1B	AL731	Dynamic brake overload			
		FF1C	AL740	Inrush current limiting resistor overload			
		FF1D	AL7A1	Internal overheat error 1 (control board)			
		FF1E	AL7A2	Internal overheat error 2 (power board)			
		FF1F	AL7A3	Internal temperature sensor error			
		FF20	AL7Ab	Drive built-in fan fault			
		FF21	AL800	Data backup error			
		FF22	AL810	Battery error			
		FF23	AL820	Encoder com. error			
		FF24	AL830	Encoder data error			
		FF25	AL840	Encoder crc error			
		FF26	AL850	Encoder counting error			
		FF27	AL860	Write data fail error			
		FF28	AL870	Encoder over heat error			
		FF29	AL880	Encoder sensor phase error (AqB)			
		FF2A	AL890	ESC ALM - Incremental encoder cable not connected			
		FF2B	AL8A0	ESC ALM - CH1 ESC side error			
		FF2C	AL8b0	ESC ALM - CH1 Encoder side error			
		FF2D	AL8C0	ESC ALM - CH2 ESC side error			
		FF2E	AL8d0	ESC ALM - CH2 Encoder side error			
		FF2F	AL8E0	Digital encoder cable not connected			
		FF30	AL8F0	ESC ALM - Internal fault			
		FF31	AL861	Motor overheated			
		FF32	ALb10	Speed reference A/D error			
		FF33	ALb11	Speed reference A/D data error			
		FF34	ALb20	Torque reference A/D error			
		FF35	ALb33	Current detection error			
		FF36	ALC10	Servomotor out of control			

Index	Sub-Index	Name			Data type	Access	PDO	Valid value		Unit
		FF37	ALC20	Phase detection error						
		FF38	ALC21	Polarity sensor error (Hall sensor)						
		FF39	ALC22	Phase information disagreement						
		FF3A	ALC50	Polarity detection failure						
		FF3B	ALC51	Overtravel detected during polarity detection						
		FF3C	ALC52	Polarity detection not completed						
		FF3D	ALC53	Out of range of motion for polarity detection						
		FF3E	ALd00	Position error too big						
		FF3F	ALd01	Position error too big alarm at Servo ON						
		FF40	ALd02	Position error too big alarm for speed limit at Servo ON						
		FF41	ALd10	Hybrid deviation error (motor to load)						
		FF42	ALd30	Position data overflow						
		FF43	ALEb1	Safety function signal input timing error						
		FF44	ALEb2	Safety function self-check error						
		FF45	ALF10	Power supply line open phase						
		FF46	ALF50	Servomotor main circuit cable disconnection (motor maybe disconnected)						
		FF47	ALFA0	Power supply for encoder error (5ve card fail)						
		FF48	ALFB0	FieldBus Hardware Fault						
		FF49	ALFB1	FieldBus Communication Fault						
		FF4A	ALFC0	Group Communication Fault						
		FF4B	ALFC1	Gantry system slave alarm						
6040h	00h	Controlword			U16	rw	Y	0x0 ~ 0xFFFF		-
		The object controls the drive's PDS state transition and the specific commands in operation mode. The details of the bits are described as below.								
		15 ... 10	9	8	7	6 ... 4	3	2	1	0
		N/A	Op mode specific	halt	Fault reset	Op mode specific	Enable operation	Quick stop	Enable voltage	Switch on
		Bit 8 (halt): If it is set to 1, the motor decelerates and stops according to object 605Dh (halt option code). Setting the bit to 0 will resume the halt operation. It is only applicable in pp, pv, tq and hm mode.								
		Bit 7, 3~0: PDS commands. The codes of the commands are described in Section 3.2.1 PDS (Power Drive System) <b>Fehler! Verweisquelle konnte nicht gefunden werden..</b>								
		Bit 9, 6~4 (operation mode specific): The availability of each bit in each mode is listed as below.								
		Op mode	9	6	5	4				
		pp	change on set-point	absolute / relative	change set immediately	new set-point				
		pv	-	-	-	-				
tq	-	-	-	-						
hm	-	-	-	homing operation start						
csp	-	-	-	-						
csv	-	-	-	-						
cst	-	-	-	-						

6041h

00h

Statusword

U16

ro

Y

0 ~ FFFFh

-

The object provides the status of PDS FSA and the specific information in operation mode. The details of the bits are described as below.

15	14	13	12	11	10	9	8	7
Reserved		Op mode specific		Internal limit active	Target reached	Remote	Reserved	Warning
6		5		4	3	2	1	0
Switch on disabled		Quick stop		Voltage enabled	Fault	Operation enabled	Switched on	Ready to Switch on

Bit 6, 5, 3~0: PDS states. The codes of the states are described in Section 3.2.1 PDS (Power Drive System).

Bit 4 (voltage enabled): If the main power is applied to PDS, the bit is set to 1.

Bit 5 (quick stop): If PDS is reacting on a quick stop request, the bit is set to 0.

Bit 7 (warning): If the bit is 1, it indicates a warning occurs. PDS does not change and the operation of the motor continues during warning (no error occurs).

Bit 9 (remote): Controlword is processed if the bit is set to 1. It will be set to 1 after ESM state becomes PreOp (SDO available).

Bit 10 (target reached):




Value	Definition
0	Halt (Bit 8 in controlword) = 0: target not reached
	Halt = 1: axis decelerates
1	Halt = 0: target reached
	Halt = 1: axis stops (velocity = 0)



Bit 11 (internal limit active): The bit is set to 1 if one of the following conditions occurs.


Op mode		Condition	Servo on / off
Position control	pp, csp	Software limit	on / off
		Hardware limit	on / off
		Torque limit	on
		Interpolation speed exceeded in csp	on
	hm	Torque limit	on
Velocity control	pv, csv	Hardware limit	on / off
		Torque limit	on
Torque control	tq, cst	Hardware limit	on / off
		Torque limit	on

Bit 13, 12, 10 (operation mode specific): The availability of each bit in each mode is listed below.

Op mode	13	12	10
pp	following error	set-point acknowledge	target reached
pv	max slippage error	speed	target reached
tq	-	-	target reached
hm	homing error	homing attained	target reached
csp	following error	drive follows command value	target reached
csv	-	drive follows command value	target reached
cst	-	drive follows command value	target reached

605Ah	00h	Quick stop option code	l16	rw	-	2	-
		The object indicates the action when quick stop function is executed. E1 drive only supports <u>option 2: slow down</u> according to 6085h (quick stop deceleration). PDS state changes to Switch on disabled.					
605Bh	00h						
		Shutdown option code					
605Ch	00h	The object indicates the action when PDS state transits from Operation enabled to Ready to switch on. E1 drive only supports <u>option 0: Disable drive function</u> . PDS state changes to Ready to switch on.					
							
605Ch	00h	Disable operation option code					
		The object indicates the action when PDS state transits from Operation enabled to Switched on. E1 drive only supports <u>option 0: Disable drive function</u> . PDS state changes to Switched on.					
605Ch	00h						

605Dh	00h	Halt option code	I16	rw	-	2	-																										
		The object indicates the action when halt function is executed. E1-series drive only supports <u>option 2: Slow down</u> on quick stop ramp. PDS state stays in Operation enabled.																															
																																	
605Eh	00h	Fault reaction option code	I16	rw	-	0 ~ 2	-																										
		The object indicates the action during Fault reaction. The supported values are described as follows. 0: Disable drive function. The motor is free to rotate. 2: Slow down according to 6085h (quick stop deceleration). PDS state changes to Fault.																															
																																	
6060h	00h	Modes of operation	I8	rw	Y	0 ~ 10	-																										
		Set the operation mode of the drive. The supported operation modes are listed as below.																															
		<table border="1"><thead><tr><th>Value</th><th>Op mode</th><th>abbreviation</th></tr></thead><tbody><tr><td>0</td><td>no mode change / assigned</td><td>-</td></tr><tr><td>1</td><td>profile position</td><td>pp</td></tr><tr><td>3</td><td>profile velocity</td><td>pv</td></tr><tr><td>4</td><td>profile torque</td><td>tq</td></tr><tr><td>6</td><td>homing</td><td>hm</td></tr><tr><td>8</td><td>cyclic synchronous position</td><td>csp</td></tr><tr><td>9</td><td>cyclic synchronous velocity</td><td>csv</td></tr><tr><td>10</td><td>cyclic synchronous torque</td><td>cst</td></tr></tbody></table>							Value	Op mode	abbreviation	0	no mode change / assigned	-	1	profile position	pp	3	profile velocity	pv	4	profile torque	tq	6	homing	hm	8	cyclic synchronous position	csp	9	cyclic synchronous velocity	csv	10
Value	Op mode	abbreviation																															
0	no mode change / assigned	-																															
1	profile position	pp																															
3	profile velocity	pv																															
4	profile torque	tq																															
6	homing	hm																															
8	cyclic synchronous position	csp																															
9	cyclic synchronous velocity	csv																															
10	cyclic synchronous torque	cst																															
The default value is 0. If the object is set to 0 or an unsupported value, there will be no mode change. Stop the motor before switching the operation mode. If the operation mode is changed during motion, the behavior will not be guaranteed. If dual-loop control is adopted, only pp, hm and csp modes can be used.																																	
6061h	00h	Modes of operation display	I8	ro	Y	0 ~ 10	-																										
The actual operation mode in the drive. The object will change to the commanded mode after internal mode is successfully changed. If the commanded mode is not supported, the object will remain unchanged.																																	
6062h	00h	Position demand value	I32	ro	Y	-2147483648 ~ 2147483647	inc																										
The required position value.																																	
6063h	00h	Position actual internal value	I32	ro	Y	-2147483648 ~ 2147483647	count																										
The actual value of motor position. In dual-loop control, the value is from external scale unit.																																	
6064h	00h	Position actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc																										
The actual value of motor position.																																	

6065h	00h	Following error window	U32	rw	Y	0 ~ 4294967295	inc
		The threshold of 60F4h (following error actual value). When 60F4h (following error actual value) exceeds 6065h, bit 13 of 6041h (statusword) will be 1. If the object is set to 0, a following error will always occur.					
6066h	00h	Following error time out	U16	rw	Y	0 ~ 65535	ms
		Refer to description of 6065h (following error window).					
6067h	00h	Position window	U32	rw	Y	0 ~ 4294967295	inc
		If the difference between 6062h (position demand value) and 6064h (position actual value) is within 6067h (position window) for longer than the time set by 6068h (position window time), bit 10 of 6041h will be set to 1. Once the position deviation exceeds 6067h, bit 10 of 6041h (statusword) will be set to 0.					
6068h	00h	Position window time	U16	rw	Y	0 ~ 65535	ms
		Refer to description of 6067h (position window).					
606Bh	00h	Velocity demand value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
		Internal command velocity					
606Ch	00h	Velocity actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
		The actual velocity of the motor.					
606Dh	00h	Velocity window	U16	rw	Y	0 ~ 65535	inc/s
		If the difference between 60FFh (target velocity) + 60B1h (velocity offset) and 606Ch (velocity actual value) is within 606Dh (velocity window) for longer than the time set by 606Eh (velocity window time), bit 10 of 6041h (statusword) will be set to 1. Once the velocity deviation exceeds 6067h (position window), bit 10 of 6041h (statusword) will be set to 0.					
606Eh	00h	Velocity window time	U16	rw	Y	0 ~ 65535	ms
		Refer to description of 606Dh (velocity window).					
6071h	00h	Target torque	I16	rw	Y	-32768 ~ 32767	0.1%
		Torque command. The value is limited by 6072h (max torque). Output target torque (force) of the drive = motor torque (force) constant x motor rated current x object 6071h (target torque) / 1000					
6072h	00h	Max torque	U16	rw	Y	0 ~ 65535	0.1%
		The configured maximum torque. The value is limited by the motor's ability.					
6074h	00h	Torque demand	I16	ro	Y	-32768 ~ 32767	0.1%
		Internal torque command.					
6075h	00h	Motor rated current	U32	ro	-	0 ~ 4294967295	mA
		The rated current of the motor.					
6076h	00h	Motor rated torque	U32	ro	-	0 ~ 4294967295	mNm
		The rated torque of the motor.					
6077h	00h	Torque actual value	I16	ro	Y	-32768 ~ 32767	0.1%
		The value is given per thousand of rated torque. The value is only for reference.					
607Ah	00h	Target position	I32	rw	Y	-2147483648 ~ 2147483647	inc
		Position command.					
607Ch	00h	Home offset	I32	rw	Y	-2147483648 ~ 2147483647	inc
		After homing procedure is done, the detected index position is set to the value of 607Ch (home offset). Zero position = home position + home offset  					

607Dh	-	Software position limit	-	-	-	-	-
		<p>To enable software limit, 3041h must be set to 1. After the position coordinate is finalized, the software limit will be effective. If the actual position is out of the normal operating range, the motor can only move towards the normal operating range, and bit 11 of 6041h (statusword) will be 1. Once the motor reaches the software limit, the motor decelerates according to 6085h (quick stop deceleration).</p>					
		00h	Number of entries	U8	ro	-	2
		01h	Min position limit	I32	rw	Y	-2147483648 ~ 2147483647
			The software limit value in negative direction.				
		02h	Max position limit	I32	rw	Y	-2147483648 ~ 2147483647
			The software limit value in positive direction.				
		00h	Max profile velocity	U32	rw	Y	0 ~ 4294967295
			The configured maximum velocity. The value is limited by the motor's ability.				
		00h	Profile velocity	U32	rw	Y	0 ~ 4294967295
			The velocity during profile motion. The value is limited by 607Fh.				
6083h	00h	Profile acceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
		The configured acceleration of profile motion.					
6084h	00h	Profile deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
		The configured deceleration of profile motion.					
6085h	00h	Quick stop deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
		The deceleration is used to stop the motor when quick stop function is activated and 605Ah (quick stop option code) is set to 2 or 6. Quick stop deceleration is also used when 605Dh (halt option code) and 605Eh (fault reaction option code) is 2.					
6087h	00h	Torque slope	U32	rw	Y	0 ~ 4294967295	0.1%/s
		The rate of change of torque.					
6098h	00h	Homing method	I8	rw	Y	-128 ~ 127	-
		The homing method used in hm mode. The homing method can not be changed during homing. The supported homing methods are method -5 to -1, 1, 2, 7 to 14, 33, 34 and 37. If homing procedure starts with unsupported homing method, bit 13 of 6041h (statusword) will be set to 1.					
6099h	-	Homing speeds	-	-	-	-	-
		The velocity during hm mode.					
	00h	Number of entries	U8	ro	-	2	-
	01h	Speed during search for switch	U32	rw	Y	0 ~ 4294967295	inc/s
		The velocity during searching for switch signal.					
	02h	Speed during search for zero	U32	rw	Y	0 ~ 4294967295	inc/s
		The velocity during searching for index signal.					
609Ah	00h	Homing acceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
		The acceleration and deceleration in hm mode.					
60B1h	00h	Velocity offset	I32	rw	Y	-2147483648 ~ 2147483647	inc/s
60B2h	00h	Torque offset	I16	rw	Y	-3000 ~ 3000	0.1%



60B8h	00h	Touch probe function	U16	rw	Y	0 ~ 65535	-	
		E1-series drive only supports touch probe 1 function. Each bit is described as below.						
		Bit	Value	Definition				
		0	0	Switch off touch probe 1				
			1	Enable touch probe 1				
		1	0	Trigger first event				
			1	Continuous				
		2~3	00	-				
			01	Trigger with Z-phase signal or position encoder				
			10	-				
11	-							
4	0	Switch off sampling at positive edge of touch probe 1						
	1	Enable sampling at positive edge of touch probe 1						
5	0	Switch off sampling at negative edge of touch probe 1						
	1	Enable sampling at negative edge of touch probe 1						
6~15		-	-					
Do not enable positive and negative edges at the same time. Otherwise, the behavior is not guaranteed.								
60B9h	00h	Touch probe status	U16	ro	Y	0 ~ 65535	-	
		The state of the touch probe function. Each bit is described as below.						
		Bit	Value	Definition				
		0	0	Touch probe 1 is switched off				
			1	Touch probe 1 is enabled				
		1	0	Touch probe 1 no positive edge value stored				
			1	Touch probe 1 positive edge value stored				
		2	0	Touch probe 1 no negative edge value stored				
			1	Touch probe 1 negative edge value stored				
		3~6		-	-			
7		-	Continuous latch status. This bit is toggled every time the latch position is updated.					
8~15		-	-					
60BAh	00h	Touch probe 1 positive edge	I32	ro	Y	-2147483648 ~ 2147483647	inc	
		The position value of touch probe 1 at positive edge.						
60BBh	00h	Touch probe 1 negative edge	I32	ro	Y	-2147483648 ~ 2147483647	inc	
		The position value of touch probe 1 at negative edge.						
60BCh	00h	Touch probe 2 positive edge	I32	ro	Y	-2147483648 ~ 2147483647	inc	
		The position value of touch probe 2 at positive edge.						
60C2h	-	Interpolation time period	-	-	-	-	-	
		The interpolation time cycle is set up automatically based on the used communication cycle.						
		Communication cycle		60C2:01h		60C2:02h		
		250μs		25		-5		
		500μs		5		-4		
		1ms		1		-3		
		2ms		2		-3		
		4ms		4		-3		
60C5h	00h	Max acceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>	
		Max deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>	
60E0h	00h	Positive torque limit value	U16	rw	Y	0 ~ 65535	0.1%	
		The configured maximum positive torque in the motor.						

60E1h	00h	Negative torque limit value	U16	rw	Y	0 ~ 65535	0.1%																																		
		The configured maximum negative torque in the motor.																																							
60F4h	00h	Following error actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc																																		
		60F4h (following error actual value) = 6062h (position demand value) – 6064h (position actual value)																																							
60FCh	00h	Position demand internal value	I32	ro	Y	-2147483648 ~ 2147483647	count																																		
		Internal command position																																							
60FDh	00h	Digital inputs	U32	ro	Y	0 ~ FFFFFFFFh	-																																		
		The input status of external input signal. The definition of each bit is as below.																																							
		<table><tr><td>31 ... 24</td><td>23</td><td>22</td><td>21</td><td>20</td><td>19</td><td>18</td></tr><tr><td>Reserved</td><td>I8</td><td>I7</td><td>I6</td><td>I5</td><td>I4</td><td>I3</td></tr><tr><td>17</td><td>16</td><td>15 ... 3</td><td>2</td><td colspan="2">1</td><td>0</td></tr><tr><td>I2</td><td>I1</td><td>Reserved</td><td>Home switch</td><td colspan="2">Positive limit switch</td><td>Negative limit switch</td></tr></table>						31 ... 24	23	22	21	20	19	18	Reserved	I8	I7	I6	I5	I4	I3	17	16	15 ... 3	2	1		0	I2	I1	Reserved	Home switch	Positive limit switch		Negative limit switch						
		31 ... 24	23	22	21	20	19	18																																	
		Reserved	I8	I7	I6	I5	I4	I3																																	
		17	16	15 ... 3	2	1		0																																	
I2	I1	Reserved	Home switch	Positive limit switch		Negative limit switch																																			
The value of each bit is defined as follows. 0: switched off 1: switched on																																									
60FEh	-	Digital outputs	-	-	-	-	-																																		
		They are used to control the external output signal.																																							
		<table><tr><td>31 ... 21</td><td>20</td><td>19</td><td>18</td><td>17</td><td>16</td><td>15 ... 0</td></tr><tr><td>Reserved</td><td>O5</td><td>O4</td><td>O3</td><td>O2</td><td>O1</td><td>Reserved</td></tr></table>						31 ... 21	20	19	18	17	16	15 ... 0	Reserved	O5	O4	O3	O2	O1	Reserved																				
		31 ... 21	20	19	18	17	16	15 ... 0																																	
	Reserved	O5	O4	O3	O2	O1	Reserved																																		
	This object controls the status of the general-purpose output signals from CN6 on E1-series drive. Subindex 1 is used to control the status of the output signals. Subindex 2 determines which output signals in subindex 1 are enabled. If drive status outputs are assigned to O1~O5 signals in object 3514h, 3515h and 3516h, the status of this object will be output in the logic of ORs. If any of these signals is assigned to functions that are enabled with object 3514h, 3515h, or 3516h, use Bit Masks in subindex 2 to disable the corresponding signal. By doing so, the signal will not be duplicated.																																								
	Brake can only be controlled by this object when servo is not on.																																								
	00h	Number of entries	U8	ro	-	2	-																																		
01h	Physical outputs	U32	rw	Y	0 ~ FFFFFFFFh	-																																			
	Control the output of the external signal. The value of each bit is defined as follows. 0: switched off 1: switched on																																								
02h	Bit mask	U32	rw	Y	0 ~ FFFFFFFFh	-																																			
	The output signal mask. The value of each bit is defined as follows. 0: disable output 1: enable output																																								
60FFh	00h	Target velocity	I32	rw	Y	-2147483648 ~ 2147483647	inc/s																																		
		Velocity command. The value is limited by 607Fh (max profile velocity).																																							
6502h	00h	Supported drive modes	U32	ro	-	0 ~ FFFFFFFFh	-																																		
		The object indicates the operation modes supported by the drive. When the bit value is 1, the operation mode is supported.																																							
		<table><tr><td>Bit</td><td>31...10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td></tr><tr><td>Op mode</td><td>-</td><td>cst</td><td>csv</td><td>csp</td><td>ip</td><td>hm</td><td>-</td><td>tq</td><td>pv</td><td>vl</td><td>pp</td></tr><tr><td>Value</td><td>0</td><td>1</td><td>1</td><td>1</td><td>0</td><td>1</td><td>0</td><td>1</td><td>1</td><td>0</td><td>1</td></tr></table>						Bit	31...10	9	8	7	6	5	4	3	2	1	0	Op mode	-	cst	csv	csp	ip	hm	-	tq	pv	vl	pp	Value	0	1	1	1	0	1	0	1	1
Bit	31...10	9	8	7	6	5	4	3	2	1	0																														
Op mode	-	cst	csv	csp	ip	hm	-	tq	pv	vl	pp																														
Value	0	1	1	1	0	1	0	1	1	0	1																														

### 3.2.1 PDS (Power Drive System)

PDS that controls the drive can be operated by 6040h (controlword) from the master, drive internal control, or error detection signal. The state of PDS is reported by 6041h (statusword) from the drive. PDS FSA (Finite State Automaton) in Figure 3.2.1.1 defines the status and the control sequence of PDS.




Figure 3.2.1.1

The events and actions of PDS state transition in E1-series drive are listed in Table 3.2.1.1. After the action is performed, the state transition will be done.

Table 3.2.1.1

Trans	Event	Action
0	An automatic transition after power-on or reset application.	Drive performs initialisation and self-test.
1	Automatic transition	Communication is activated.
2	Receive "Shutdown" command.	None
3	Receive "Switch on" command when high-level power is on.	None
4	Receive "Enable operation" command.	The drive function is enabled and all internal set-points are cleared.
5	Receive "Disable operation" command.	The drive function is disabled.

6	Receive "Shutdown" command.	None
7	1. Receive "Quick stop" or "Disable voltage" command. 2. ESM is in Init state.	None
8	Receive "Shutdown" command.	The drive function is disabled.
9	Receive "Disable voltage" command.	The drive function is disabled.
10	1. Receive "Quick stop" or "Disable voltage" command. 2. ESM is in Init state.	None
11	Receive "Quick stop" command.	"Quick stop" function starts.
12	An automatic transition when "Quick stop" function is completed	The drive function is disabled.
13	The drive detects an error.	The configured fault reaction function is executed.
14	An automatic transition after deceleration process is completed	The drive function is disabled.
15	Receive "Fault reset" command.	Reset the fault condition if no fault exists currently on the drive.

## ■ PDS command code

Table 3.2.1.2

Command	Bits of 6040h (controlword)					Transition
	Bit 7	Bit 3	Bit 2	Bit 1	Bit 0	
Shutdown	0	X	1	1	0	2, 6, 8
Switch on	0	0	1	1	1	3
Switch on + Enable operation	0	1	1	1	1	3+4*
Disable voltage	0	X	X	0	X	7, 9, 10, 12
Quick stop	0	X	0	1	X	7, 10, 11
Disable operation	0	0	1	1	1	5
Enable operation	0	1	1	1	1	4
Fault reset	0→1	X	X	X	X	15

\*It will automatically transit to "Enable operation" after "Switched on" is executed.

## ■ PDS state code

Table 3.2.1.3

6041h (statusword)	PDS FSA state
xxxx xxxx x0xx 0000b	Not ready to switch on
xxxx xxxx x1xx 0000b	Switch on disabled
xxxx xxxx x01x 0001b	Ready to switch on
xxxx xxxx x01x 0011b	Switched on
xxxx xxxx x01x 0111b	Operation enabled
xxxx xxxx x00x 0111b	Quick stop active
xxxx xxxx x0xx 1111b	Fault reaction active
xxxx xxxx x0xx 1000b	Fault

## ■ The procedure of clearing errors

There are drive errors and EtherCAT related communication errors. The procedure of clearing errors are described as follows.

If there is a drive error,

- (1) Eliminate the cause of the drive error.
- (2) Execute "Fault reset" command to clear the drive's error status.

If there is a EtherCAT related communication error,

- (1) Eliminate the cause of the communication error.
- (2) Set bit 4 of AL control register to 1 to clear the error state in ESC.
- (3) Master commands the drive to change ESM state to Op.
- (4) Master change bit 7 of 6040h (controlword) from 0 to 1 in Fault state to reset fault.
- (5) After the error is cleared, the PDS state changes from Fault to Switch on disabled.




Figure 3.2.1.2

**Note:** Be sure to eliminate all errors detected before clearing error status.

## 3.2.2 Profile position mode (pp)

Profile position mode is for moving to the target position at the profile velocity and the profile acceleration. The structure of the trajectory generation is shown in Figure 3.2.2.1.




Figure 3.2.2.1

Related objects for pp mode are listed in Table 3.2.2.1.

Table 3.2.2.1

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
6040h	00h	Controlword	U16	rw	Y	0x0 ~ 0xFFFF	-
6041h	00h	Statusword	U16	ro	Y	0x0 ~ 0xFFFF	-
6062h	00h	Position demand value	I32	ro	Y	-2147483648 ~ 2147483647	inc
6063h	00h	Position actual internal value	I32	ro	Y	-2147483648 ~ 2147483647	count
6064h	00h	Position actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc
6065h	00h	Following error window	U32	rw	Y	0 ~ 4294967295	inc
6066h	00h	Following error time out	U16	rw	Y	0 ~ 65535	ms
6067h	00h	Position window	U32	rw	Y	0 ~ 4294967295	inc
6068h	00h	Position window time	U16	rw	Y	0 ~ 65535	ms
606Ch	00h	Velocity actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
6072h	00h	Max torque	U16	rw	Y	0 ~ 65535	0.1%
6074h	00h	Torque demand	I16	ro	Y	-32768 ~ 32767	0.1%
6076h	00h	Motor rated torque	U32	ro	-	0 ~ 4294967295	mNm
6077h	00h	Torque actual value	I16	ro	Y	-32768 ~ 32767	0.1%
607Ah	00h	Target position	I32	rw	Y	-2147483648 ~ 2147483647	inc
607Dh	-	Software position limit	-	-	-	-	-
	00h	Number of entries	U8	ro	-	2	-

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
	01h	Min position limit	I32	rw	Y	-2147483648 ~ 2147483647	inc
	02h	Max position limit	I32	rw	Y	-2147483648 ~ 2147483647	inc
607Fh	00h	Max profile velocity	U32	rw	Y	0 ~ 4294967295	inc/s
6081h	00h	Profile velocity	U32	rw	Y	0 ~ 4294967295	inc/s
6083h	00h	Profile acceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
6084h	00h	Profile deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
6085h	00h	Quick stop deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
60C5h	00h	Max acceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
60C6h	00h	Max deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
60F4h	00h	Following error actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc
60FCh	00h	Position demand internal value	I32	ro	Y	-2147483648 ~ 2147483647	count

## ■ Controlword (6040h) for pp mode

Table 3.2.2.2

Bit 9	Bit 5	Bit 4	Definition
change on set-point	change set immediately	new set-point	
0	0	0→1	Positioning is completed (target reached) before the next one gets started.
X	1	0→1	Immediately start next positioning.
1	0	0→1	Execute positioning with current profile velocity to the current set-point and then apply next positioning.

Table 3.2.2.3

Bit	Value	Definition
6 (absolute / relative)	0	Target position is an absolute value.
	1	Target position is a relative value.
8 (halt)	0	Execute or continue positioning.
	1	Axis is stopped according to 605Dh (halt option code).

## ■ Statusword (6041h) for pp mode

Table 3.2.2.4

Bit	Value	Definition
10 (target reached)	0	Halt (Bit 8 in controlword) = 0: target position not reached Halt = 1: axis decelerates
	1	Halt = 0: target position reached Halt = 1: velocity of axis is 0
12 (set-point acknowledge)	0	The last set-point is already processed. Wait for new set-point (the buffer is empty).
	1	Previous set-point is still in process.
13 (following error)	0	No following error
	1	Following error

## ■ Example of setting basic set-point

- [1] The master sets 607Ah (target position), and then sets bit 4 of 6040h (controlword) from 0 to 1 (edge trigger).
- [2] The drive acknowledges the new set-point by setting bit 12 of 6041h (statusword) to 1. Then, the drive starts to move toward target position from 607Ah (target position).
- [3] The master sets bit 4 of 6040h (controlword) to 0 after bit 12 of 6041h (statusword) is set to 1.
- [4] The drive sets bit 12 of 6041h (statusword) to 0 after bit 4 of 6040h (controlword) is set to 0.
- [5] When the motor reaches the target position, the drive sets bit 10 of 6041h (statusword) to 1.




Figure 3.2.2.2

**Note:** The velocity of the motion is from 6081h (profile velocity), which is limited by 607Fh (max profile velocity).



## ■ Example of setting single set-point

When bit 5 of 6040h (controlword) is 1, the new set-point is immediately validated by bit 4 of 6040h (controlword). Thus, the set-point in progress will be interrupted.

- [1] After bit 12 of 6041h (statusword) is set to 0, the master changes the value of 607Ah (target position) and set bit 4 of 6040h from 0 to 1 (edge trigger).
- [2] The drive acknowledges the new set-point by setting bit 12 of 6041h (statusword) to 1. Then, the drive starts to move toward the new target position from 607Ah (target position).
- [3] The master sets bit 4 of 6040h (controlword) to 0 after bit 12 of 6041h (statusword) is set to 1.
- [4] The drive sets bit 12 of 6041h (statusword) to 0 after bit 4 of 6040h (controlword) is set to 0.




Figure 3.2.2.3

## ■ Example of setting set of set-points (change target during motion)

- [1] After bit 12 of 6041h (statusword) is set to 0, the master changes the value of 607Ah (target position) and set bit 4 of 6040h (controlword) from 0 to 1 (edge trigger).
- [2] The drive acknowledges the new set-point by setting bit 12 of 6041h (statusword) to 1. The drive buffers 607Ah (target position) as a new target position and continues the ongoing target position.
- [3] The master sets bit 4 of 6040h (controlword) to 0 after bit 12 of 6041h (statusword) is set to 1.
- [4] The drive starts to move to the new target position after the ongoing set-point is completed. Then, the buffer becomes empty, and bit 12 of 6041h (statusword) is set to 0.




Figure 3.2.2.4

**Note:** If the new target position is in the opposite direction, the motor will stop at the previous target position, and a reverse operation will be performed.

## ■ Example of buffering set-points

E1-series drive only supports 2 set-points maximum. The handling of the set-points is shown as follows.

- [1] When there is no set-point in progress, a new set-point A is immediately effective.
- [2] When there is a set-point in progress, the new set-point B and C are stored in the buffers.
- [3] When all set-point buffers are all in use (bit 12 of 6041h is 1), the new set-point D is discarded.
- [4] When all set-point buffers are all in use (bit 12 of 6041h is 1) and bit 5 of 6040h (controlword) is set to 1, the new set-point E is immediately processed as a single set-point. All previous setpoints are discarded.
- [5] Bit 10 of 6041h (statusword) remains 0 until all set-points are processed.




Figure 3.2.2.5

## ■ Example of halt bit

When bit 8 of 6040h (controlword) is set to 1 in pp mode, the motion will be temporarily stopped. After bit 8 of 6040h (controlword) returns to 0, unfinished set-points will be resumed.

- [1] When there is no set-point in process, the new set-point A is taken immediately.
- [2] When set-point A is still in process, the new set-point B is stored if the buffer is empty.
- [3] When set-point A is still in process but bit 8 of 6040h (controlword) is set to 1, the motion is halted. After the motor speed decelerates to 0, bit 10 of 6041h (statusword) changes to 1.
- [4] When bit 8 of 6040h (controlword) returns to 0, the motion towards set-point A is resumed. Bit 10 of 6041h (statusword) changes to 0.
- [5] After set-point A is reached, set-point B is processed.
- [6] Bit 10 of 6041h (statusword) remains 0 until all set-points are processed.




Figure 3.2.2.6

### 3.2.3 Cyclic synchronous position mode (csp)

The motion profile (trajectory) is generated by the master. Therefore, the position command is updated by the master every communication cycle. Cyclic synchronous position mode is used in DC mode. Before enabling the motor in csp mode or switching to csp mode, be sure to align 607Ah (target position) with 6064h (position actual value) first. Otherwise, it may cause dangerous behavior. If the change amount of 607Ah (target position) exceeds the following speed range, the target position will be ignored.

$$\frac{(\text{Target position (607Ah)} - \text{Position demand value (6062h)})}{\text{Interpolation time period (60C2h)}} < \text{Velocity limit (2316h) [unit:prm]}$$

The structure of the trajectory generation is shown in Figure 3.2.3.1.




Figure 3.2.3.1

Related objects for csp mode are listed in Table 3.2.3.1.

Table 3.2.3.1

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
6040h	00h	Controlword	U16	rw	Y	0x0 ~ 0xFFFF	-
6041h	00h	Statusword	U16	ro	Y	0x0 ~ 0xFFFF	-
6062h	00h	Position demand value	I32	ro	Y	-2147483648 ~ 2147483647	inc
6063h	00h	Position actual internal value	I32	ro	Y	-2147483648 ~ 2147483647	count
6064h	00h	Position actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc
6065h	00h	Following error window	U32	rw	Y	0 ~ 4294967295	inc
6066h	00h	Following error time out	U16	rw	Y	0 ~ 65535	ms
606Ch	00h	Velocity actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
6072h	00h	Max torque	U16	rw	Y	0 ~ 65535	0.1%
6074h	00h	Torque demand	I16	ro	Y	-32768 ~ 32767	0.1%
6076h	00h	Motor rated torque	U32	ro	-	0 ~ 4294967295	mNm
6077h	00h	Torque actual value	I16	ro	Y	-32768 ~ 32767	0.1%
607Ah	00h	Target position	I32	rw	Y	-2147483648 ~ 2147483647	inc
607Dh	-	Software position limit	-	-	-	-	-
	00h	Number of entries	U8	ro	-	2	-
	01h	Min position limit	I32	rw	Y	-2147483648 ~ 2147483647	inc
	02h	Max position limit	I32	rw	Y	-2147483648 ~ 2147483647	inc
6084h	00h	Profile deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
6085h	00h	Quick stop deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
60B1h	00h	Velocity offset	I32	rw	Y	-2147483648 ~ 2147483647	inc/s
60B2h	00h	Torque offset	I16	rw	Y	-32768 ~ 32767	0.1%
60C2h	-	Interpolation time period	-	-	-	-	-
	00h	Number of entries	U8	ro	-	2	-
	01h	Interpolation time period value	U8	rw	-	0 ~ 255	-
	02h	Interpolation time index	I8	rw	-	-128 ~ 63	-
60F4h	00h	Following error actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc
60FCh	00h	Position demand internal value	I32	ro	Y	-2147483648 ~ 2147483647	count

## ■ Statusword (6041h) for csp mode

Table 3.2.3.2

Bit	Value	Definition
12 (drive follows command value)	0	Drive does not follow the command value. (Ignore target position.)
	1	Drive follows the command value. (Target position is viewed as an input to position control loop.)
13 (following error)	0	No following error
	1	Following error

### 3.2.4 Homing mode (hm)

This mode is for incremental encoder. After homing procedure is done, the home position of the machine will be found. To make position zero offset from the home position, add home offset to the home position. After homing is completed, the values of the following objects are set accordingly.

6062h (position demand value) = 6064h (position actual value) = 607Ch (home offset)

6063h (position actual internal value) = 60FCh (position demand internal value) = 0

The input and output objects of hm mode are shown in Figure 3.2.4.1.




Figure 3.2.4.1

Related objects for hm mode are listed in Table 3.2.4.1.

Table 3.2.4.1

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
6040h	00h	Controlword	U16	rw	Y	0x0 ~ 0xFFFF	-
6041h	00h	Statusword	U16	ro	Y	0x0 ~ 0xFFFF	-
6062h	00h	Position demand value	I32	ro	Y	-2147483648 ~ 2147483647	inc
6063h	00h	Position actual internal value	I32	ro	Y	-2147483648 ~ 2147483647	count
6064h	00h	Position actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc
606Ch	00h	Velocity actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
6072h	00h	Max torque	U16	rw	Y	0 ~ 65535	0.1%
6074h	00h	Torque demand	I16	ro	Y	-32768 ~ 32767	0.1%
6076h	00h	Motor rated torque	U32	ro	-	0 ~ 4294967295	mNm
6077h	00h	Torque actual value	I16	ro	Y	-32768 ~ 32767	0.1%
607Ch	00h	Home offset	I32	rw	Y	-2147483648 ~ 2147483647	inc
607Fh	00h	Max profile velocity	U32	rw	Y	0 ~ 4294967295	inc/s
6085h	00h	Quick stop deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
6098h	00h	Homing method	I8	rw	Y	-128 ~ 127	-
6099h	-	Homing speeds	-	-	-	-	-
	00h	Number of entries	U8	ro	-	2	-
	01h	Speed during search for switch	U32	rw	Y	0 ~ 4294967295	inc/s
	02h	Speed during search for zero	U32	rw	Y	0 ~ 4294967295	inc/s
609Ah	00h	Homing acceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
60C5h	00h	Max acceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
60C6h	00h	Max deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>

## ■ Controlword (6040h) for hm mode

Table 3.2.4.2

Bit	Value	Definition
4 (homing operation start)	0	Do not start homing procedure.
	1	Start or continue homing procedure.
8 (halt)	0	Enable bit 4.
	1	Stop axis.

## ■ Statusword (6041h) for hm mode

Table 3.2.4.3

Bit 13	Bit 12	Bit 10	Definition
homing error	homing attained	target reached	
0	0	0	Homing procedure is in progress.
0	0	1	Homing procedure is interrupted or not started.
0	1	0	Homing is attained, but target is not reached.
0	1	1	Homing procedure is successfully completed.
1	0	0	Homing error occurs, and velocity is not 0.
1	0	1	Homing error occurs, and velocity is 0.
1	1	X	Reserved

### Note:

- Bit 12 will be cleared to zero in the following cases.
  - The drive is power cycled
  - The operation mode is changed to other modes.
- If multi-turn absolute encoder is used, bit 12 will always be 1.



■ Example of successful homing procedure

- [1] Set 6098h (homing method) to the required homing method. Homing methods supported by E1-series CoE drive are given in Table 3.2.4.4.
- [2] Accordingly set homing parameters, 609Ah (homing acceleration), 6099:01h (speed during search for switch), 6099:02h (speed during search for zero) and 607Ch (home offset).
- [3] Set bit 4 of 6040h (controlword) from 0 to 1. Then, the homing procedure starts.
- [4] When the homing procedure is successfully completed, the drive sets bit 10 and bit 12 of 6041h (statusword) to 1.










Figure 3.2.4.2

Table 3.2.4.4

Method	Description
1	<p><b>Homing on negative limit switch and index pulse</b></p> <p>If the negative limit switch is inactive, the initial direction of the movement is leftward. The home position is at the first index pulse to the right of the position where the negative limit switch becomes inactive. If the negative limit is not assigned, homing will fail.</p> 
2	<p><b>Homing on positive limit switch and index pulse</b></p> <p>If the positive limit switch is inactive, the initial direction of the movement is rightward. The home position is at the first index pulse to the left of the position where the positive limit switch becomes inactive. If the positive limit is not assigned, homing will fail.</p> 
7~10	<p><b>Homing on home switch and index pulse – positive initial direction</b></p> <p>The initial direction of the movement depends on the home switch edge being sought. If the home switch is active at the beginning, the initial direction of method 7 and 8 is negative. The initial direction of all other cases is positive. If the home switch and the positive limit are not assigned, homing will fail.</p> 
11~14	<p><b>Homing on home switch and index pulse – negative initial direction</b></p> <p>The initial direction of the movement depends on the home switch edge being sought. If the home switch is active at the beginning, the initial direction of method 11 and 12 is positive. The initial direction of all other cases is negative. If the home switch and the negative limit are not assigned, homing will fail.</p>

Method	Description
	
33~34	<p><b>Homing on index pulse</b> The direction of homing is negative (33) or positive (34) respectively. The home position is at the index pulse found in the selected direction.</p> 
37	<p><b>Homing on current position</b> Current position of the motor is defined as the home position. In this method, the drive does not need to be in Operation enabled state. Objects are initialized as follows.</p> <p>6062h (position demand value) = 6064h (position actual value) = 607Ch (home offset) 6063h (position actual internal value) = 60FCh (position demand internal value) = 0</p> 

## 3.2.5 Profile velocity mode (pv)

The motor speed is output according to the profile acceleration and the profile deceleration until it reaches the target velocity. The structure of the trajectory generation is shown in Figure 3.2.5.1.




Figure 3.2.5.1

Related objects for pv mode are listed in Table 3.2.5.1.

Table 3.2.5.1

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
6040h	00h	Controlword	U16	rw	Y	0x0 ~ 0xFFFF	-
6041h	00h	Statusword	U16	ro	Y	0x0 ~ 0xFFFF	-
6062h	00h	Position demand value	I32	ro	Y	-2147483648 ~ 2147483647	inc
6063h	00h	Position actual internal value	I32	ro	Y	-2147483648 ~ 2147483647	count
6064h	00h	Position actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc
606Bh	00h	Velocity demand value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
606Ch	00h	Velocity actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
606Dh	00h	Velocity window	U16	rw	Y	0 ~ 65535	inc/s
606Eh	00h	Velocity window time	U16	rw	Y	0 ~ 65535	ms
6072h	00h	Max torque	U16	rw	Y	0 ~ 65535	0.1%
6076h	00h	Motor rated torque	U32	ro	-	0 ~ 4294967295	mNm
6077h	00h	Torque actual value	I16	ro	Y	-32768 ~ 32767	0.1%
607Fh	00h	Max profile velocity	U32	rw	Y	0 ~ 4294967295	inc/s
6083h	00h	Profile acceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
6084h	00h	Profile deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
6085h	00h	Quick stop deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
60C5h	00h	Max acceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
60C6h	00h	Max deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
60FFh	00h	Target velocity	I32	rw	Y	-2147483648 ~ 2147483647	inc/s

■ Controlword (6040h) for pv mode

Table 3.2.5.2

Bit	Value	Definition
8 (halt)	0	Execute or continue the motion.
	1	Axis is stopped according to 605Dh (halt option code).

■ Statusword (6041h) for pv mode

Table 3.2.5.3

Bit	Value	Definition
10 (target reached)	0	Halt (Bit 8 in controlword) = 0: target velocity not reached Halt = 1: axis decelerates
	1	Halt = 0: target velocity reached Halt = 1: velocity of axis is 0
12 (speed)	0	Speed is not equal to 0.
	1	Speed is equal to 0.

## 3.2.6 Cyclic synchronous velocity mode (csv)

The motion profile (trajectory) is generated by the master. 60C2h (interpolation time period) indicates the cycle of updating 60FFh (target velocity). The structure of the trajectory generation is shown in Figure 3.2.6.1.




Figure 3.2.6.1

Related objects for csv mode are listed in Table 3.2.6.1.

Table 3.2.6.1

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
6040h	00h	Controlword	U16	rw	Y	0x0 ~ 0xFFFF	-
6041h	00h	Statusword	U16	ro	Y	0x0 ~ 0xFFFF	-
6063h	00h	Position actual internal value	I32	ro	Y	-2147483648 ~ 2147483647	count
6064h	00h	Position actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc
606Bh	00h	Velocity demand value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
606Ch	00h	Velocity actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
606Dh	00h	Velocity window	U16	rw	Y	0 ~ 65535	inc/s
606Eh	00h	Velocity window time	U16	rw	Y	0 ~ 65535	ms
6072h	00h	Max torque	U16	rw	Y	0 ~ 65535	0.1%
6074h	00h	Torque demand	I16	ro	Y	-32768 ~ 32767	0.1%
6076h	00h	Motor rated torque	U32	ro	-	0 ~ 4294967295	mNm
6077h	00h	Torque actual value	I16	ro	Y	-32768 ~ 32767	0.1%
6085h	00h	Quick stop deceleration	U32	rw	Y	0 ~ 4294967295	inc/s <sup>2</sup>
60B1h	00h	Velocity offset	I32	rw	Y	-2147483648 ~ 2147483647	inc/s
60B2h	00h	Torque offset	I16	rw	Y	-32768 ~ 32767	0.1%
60C2h	-	Interpolation time period	-	-	-	-	-
	00h	Number of entries	U8	ro	-	2	-
	01h	Interpolation time period value	U8	rw	-	0 ~ 255	-
	02h	Interpolation time index	I8	rw	-	-128 ~ 63	-
60FFh	00h	Target velocity	I32	rw	Y	-2147483648 ~ 2147483647	inc/s

## ■ Statusword (6041h) for csv mode

Table 3.2.6.2

Bit	Value	Definition
12 (drive follows command value)	0	Drive does not follow the command value. (Ignore target velocity.)
	1	Drive follows the command value. (Target velocity is viewed as an input to velocity control loop.)

### 3.2.7 Profile torque mode (tq)

The torque is output up to the target torque according to the torque slope setting. Torque command is generated from 6071h (target torque) and 6087h (torque slope), as Figure 3.2.7.1 shows.




Figure 3.2.7.1

The structure of the trajectory generation is shown in Figure 3.2.7.2.




Figure 3.2.7.2

Related objects for tq mode are listed in Table 3.2.7.1.

Table 3.2.7.1

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
6040h	00h	Controlword	U16	rw	Y	0x0 ~ 0xFFFF	-
6041h	00h	Statusword	U16	ro	Y	0x0 ~ 0xFFFF	-
6063h	00h	Position actual internal value	I32	ro	Y	-2147483648 ~ 2147483647	count
6064h	00h	Position actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc
606Ch	00h	Velocity actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
6071h	00h	Target torque	I16	rw	Y	-32768 ~ 32767	0.1%
6072h	00h	Max torque	U16	rw	Y	0 ~ 65535	0.1%
6074h	00h	Torque demand	I16	ro	Y	-32768 ~ 32767	0.1%
6075h	00h	Motor rated current	U32	ro	-	0 ~ 4294967295	mA
6076h	00h	Motor rated torque	U32	ro	-	0 ~ 4294967295	mNm
6077h	00h	Torque actual value	I16	ro	Y	-32768 ~ 32767	0.1%
6087h	00h	Torque slope	U32	rw	Y	0 ~ 4294967295	0.1%/s
60B2h	00h	Torque offset	I16	rw	Y	-32768 ~ 32767	0.1%
60E0h	00h	Positive torque limit value	U16	rw	Y	0 ~ 65535	0.1%
60E1h	00h	Negative torque limit value	U16	rw	Y	0 ~ 65535	0.1%

## ■ Controlword (6040h) for tq mode

Table 3.2.7.2

Bit	Value	Definition
8 (halt)	0	Execute or continue the motion.
	1	Axis is stopped according to 605Dh (halt option code).

## ■ Statusword (6041h) for tq mode

Table 3.2.7.3

Bit	Value	Definition
10 (target reached)	0	Halt (Bit 8 in controlword) = 0: target torque not reached Halt = 1: axis decelerates
	1	Halt = 0: target torque reached Halt = 1: velocity of axis is 0



### 3.2.8 Cyclic synchronous torque mode (cst)

The motion profile (trajectory) is generated by the master. 60C2h (interpolation time period) indicates the cycle of update 6071h (target torque). The structure of the trajectory generation is shown in Figure 3.2.8.1.




Figure 3.2.8.1

Related objects for cst mode are listed in Table 3.2.8.1.

Table 3.2.8.1

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
6040h	00h	Controlword	U16	rw	Y	0x0 ~ 0xFFFF	-
6041h	00h	Statusword	U16	ro	Y	0x0 ~ 0xFFFF	-
6063h	00h	Position actual internal value	I32	ro	Y	-2147483648 ~ 2147483647	count
6064h	00h	Position actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc
606Ch	00h	Velocity actual value	I32	ro	Y	-2147483648 ~ 2147483647	inc/s
6071h	00h	Target torque	I16	rw	Y	-32768 ~ 32767	0.1%
6072h	00h	Max torque	U16	rw	Y	0 ~ 65535	0.1%
6074h	00h	Torque demand	I16	ro	Y	-32768 ~ 32767	0.1%
6075h	00h	Motor rated current	U32	ro	-	0 ~ 4294967295	mA
6076h	00h	Motor rated torque	U32	ro	-	0 ~ 4294967295	mNm
6077h	00h	Torque actual value	I16	ro	Y	-32768 ~ 32767	0.1%
60B2h	00h	Torque offset	I16	rw	Y	-32768 ~ 32767	0.1%
60C2h	-	Interpolation time period	-	-	-	-	-
	00h	Number of entries	U8	ro	-	2	-
	01h	Interpolation time period value	U8	rw	-	0 ~ 255	-
	02h	Interpolation time index	I8	rw	-	-128 ~ 63	-
60E0h	00h	Positive torque limit value	U16	rw	Y	0 ~ 65535	0.1%
60E1h	00h	Negative torque limit value	U16	rw	Y	0 ~ 65535	0.1%

## ■ Statusword (6041h) for cst mode

Table 3.2.8.2

Bit	Value	Definition
12 (drive follows command value)	0	Drive does not follow the command value. (Ignore target torque.)
	1	Drive follows the command value. (Target torque is viewed as an input to torque control loop.)

## 3.2.9 Touch probe function

The function latches feedback position triggered by the index signal (Z-phase). If the function is enabled during the usage of absolute encoder, error occurs. When the operation mode is homing mode, the touch probe function is disabled. Do not set rising edge and falling edge at the same time.

Related objects for touch probe function are listed in Table 3.2.9.1.

Table 3.2.9.1

Index	Sub-Index	Name	Data type	Access	PDO	Valid value	Unit
60B8h	00h	Touch probe function	U16	rw	Y	0 ~ 65535	-
60B9h	00h	Touch probe status	U16	ro	Y	0 ~ 65535	-
60BAh	00h	Touch probe 1 positive edge	I32	ro	Y	-2147483648 ~ 2147483647	inc
60BBh	00h	Touch probe 1 negative edge	I32	ro	Y	-2147483648 ~ 2147483647	inc
60BCh	00h	Touch probe 2 positive edge	I32	ro	Y	-2147483648 ~ 2147483647	inc

■ Example of touch probe 1 triggering first event




Figure 3.2.9.1

Table 3.2.9.2

#	Value	Description
(1)	60B8h bit 0 = 1 60B8h bit 1 = 0 60B8h bit 4 = 1	Enable touch probe 1. Trigger first event. Configure and enable touch probe 1 positive edge.
(2)	→ 60B9h bit 0 = 1	Status "Touch probe 1 enables" is set.
(3)		There is a positive edge in external touch probe signal.
(4)	→ 60B9h bit 1 = 1 → 60BAh	Status "Touch probe 1 positive edge stored" is set. Touch probe position 1 positive value is stored.
(5)	60B8h bit 4 = 0	Positive edge sample is disabled.
(6)	→ 60B9h bit 1 = 0 → 60BAh	Status "Touch probe 1 positive edge stored" is reset. Touch probe position 1 positive value is not changed.
(7)	60B8h bit 4 = 1	Positive edge sample is enabled.
(8)		There is a positive edge in external touch probe signal.
(9)	→ 60B9h bit 1 = 1 → 60BAh	Status "Touch probe 1 positive edge stored" is set. Touch probe position 1 positive value is stored.
(10)	→ 60B8h bit 0 = 0	Touch probe 1 is disabled.
(11)	→ 60B9h bit 0 and bit 1 = 0	Status bits are reset.

## ■ Example of touch probe 1 continuous mode




Figure 3.2.9.2

Table 3.2.9.3

#	Value	Description
(1)	60B8h bit 0 = 1 60B8h bit 1 = 1 60B8h bit 4 = 1	Enable touch probe 1. Continuous state. Configure and enable touch probe 1 positive edge.
(2)	→ 60B9h bit 0 = 1	Status "Touch probe 1 enables" is set.
(3)		There is a positive edge in external touch probe signal.
(4)	→ 60B9h bit 1 = 1 → 60B9h bit 7 = 1 → 60BAh	Status "Touch probe 1 positive edge stored" is set. Touch probe 1 positive edge is updated. Touch probe position 1 positive value is stored.
(5)		There is a positive edge in external touch probe signal.
(6)	→ 60B9h bit 7 = 0 → 60BAh	Touch probe 1 positive edge is updated. Touch probe position 1 positive value is stored.
(7)		There is a positive edge in external touch probe signal.
(8)	→ 60B9h bit 7 = 0 → 60BAh	Touch probe 1 positive edge is updated. Touch probe position 1 positive value is stored.
(9)	60B8h bit 4 = 0	Positive edge sample is disabled.
(10)	→ 60B9h bit 1 = 0 → 60B9h bit 7 = 0 → 60BAh	Status "Touch probe 1 positive edge stored" is reset. Continuous latch status is reset. Touch probe position 1 positive value is not changed.
(11)	→ 60B8h bit 0 = 0	Touch probe 1 is disabled.
(12)	→ 60B9h bit 0 = 0	Status bit is reset.

## 3.3 Manufacturer specific profile area

The 2000h series objects are from servo parameters. Please refer to “E1 Series Servo Drive User Manual” for more information. The mapping relationship between servo parameter numbers and object indexes is as follows:

Object index = 2000h + servo parameter number

### 3.3.1 Absolute encoder initialization

When using a rotary absolute encoder, it is necessary to clear multi-turn data at the first start up after installing the battery. There are two types of data in a rotary absolute encoder, single-turn data and multi-turn data. The single-turn data shows the position of the motor's rotation within a single turn. The multi-turn data counts the number of the turns, and the backup is stored by the battery.

The position information of the drive is based on the following formulas, where M is multi-turn data and S is single-turn data.

6063h (position actual internal value) = M x encoder resolution + S

6064h (position actual value) = 6063h x electronic gear + 607Ch (home offset)

Keep servo off until the procedure of clearing data is finished. After that, power cycle the drive.

#### ■ The procedure of clearing multi-turn data via EtherCAT

Step 1. Disable the motor.

Step 2. Set 3200h to 1.

Step 3. Set 1010h to 0x65766173.

Step 4. Reset the drive.

## 3.4 Object dictionary list

Table 3.4.1

Index	Sub-Index	Name	Data type	Access	PDO	Op Mode	Valid value	Unit
1000h	00h	Device type	U32	ro	-	All	0x00020192	-
1001h	00h	Error register	U8	ro	-	All	0x0 ~ 0xFF	-
1010h	-	Store parameters	-	-	-		-	-
	00h	Number of entries	U8	ro	-	All	1	-
	01h	Save all parameters	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
1018h	-	Identity object	-	-	-		-	-
	00h	Number of entries	U8	ro	-	All	4	-
	01h	Vendor ID	U32	ro	-	All	0xAAAA	-
	02h	Product code	U32	ro	-	All	0x05	-
	03h	Revision number	U32	ro	-	All	0 ~ 4294967295	-
	04h	Serial number	U32	ro	-	All	0 ~ 4294967295	-
10F1h	-	Error settings	-	-	-		-	-
	00h	Number of entries	U8	ro	-	All	1	-
	02h	Sync error counter limit	U16	rw	-	All	0 ~ 15	-
1600h	-	1 <sup>st</sup> RxPDO mapping	-	-	-	-	-	-
	00h	Number of entries	U8	rw	-	All	0 ~ 8	-
	01h	Mapping entry 1	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	02h	Mapping entry 2	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	03h	Mapping entry 3	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	04h	Mapping entry 4	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	05h	Mapping entry 5	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	06h	Mapping entry 6	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	07h	Mapping entry 7	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
1601h	-	2 <sup>nd</sup> RxPDO mapping	-	-	-	-	-	-
	00h	Number of entries	U8	rw	-	All	0 ~ 8	-
	01h	Mapping entry 1	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	02h	Mapping entry 2	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	03h	Mapping entry 3	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	04h	Mapping entry 4	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	05h	Mapping entry 5	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	06h	Mapping entry 6	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	07h	Mapping entry 7	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
1602h	-	3 <sup>rd</sup> RxPDO mapping	-	-	-	-	-	-
	00h	Number of entries	U8	rw	-	All	0 ~ 8	-
	01h	Mapping entry 1	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	02h	Mapping entry 2	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	03h	Mapping entry 3	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	04h	Mapping entry 4	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	05h	Mapping entry 5	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-

Index	Sub-Index	Name	Data type	Access	PDO	Op Mode	Valid value	Unit
	06h	Mapping entry 6	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	07h	Mapping entry 7	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	08h	Mapping entry 8	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
1603h	-	4 <sup>th</sup> RxPDO mapping	-	-	-	-	-	-
	00h	Number of entries	U8	rw	-	All	0 ~ 8	-
	01h	Mapping entry 1	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	02h	Mapping entry 2	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	03h	Mapping entry 3	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	04h	Mapping entry 4	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	05h	Mapping entry 5	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	06h	Mapping entry 6	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	07h	Mapping entry 7	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	08h	Mapping entry 8	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
1A00h	-	1 <sup>st</sup> TxPDO mapping	-	-	-	-	-	-
	00h	Number of entries	U8	rw	-	All	0 ~ 8	-
	01h	Mapping entry 1	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	02h	Mapping entry 2	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	03h	Mapping entry 3	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	04h	Mapping entry 4	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	05h	Mapping entry 5	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	06h	Mapping entry 6	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	07h	Mapping entry 7	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	08h	Mapping entry 8	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
1A01h	-	2 <sup>nd</sup> TxPDO mapping	-	-	-	-	-	-
	00h	Number of entries	U8	rw	-	All	0 ~ 8	-
	01h	Mapping entry 1	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	02h	Mapping entry 2	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	03h	Mapping entry 3	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	04h	Mapping entry 4	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	05h	Mapping entry 5	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	06h	Mapping entry 6	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	07h	Mapping entry 7	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	08h	Mapping entry 8	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
1A02h	-	3 <sup>rd</sup> TxPDO mapping	-	-	-	-	-	-
	00h	Number of entries	U8	rw	-	All	0 ~ 8	-
	01h	Mapping entry 1	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	02h	Mapping entry 2	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	03h	Mapping entry 3	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	04h	Mapping entry 4	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	05h	Mapping entry 5	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	06h	Mapping entry 6	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	07h	Mapping entry 7	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	08h	Mapping entry 8	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
1A03h	-	4 <sup>th</sup> TxPDO mapping	-	-	-	-	-	-
	00h	Number of entries	U8	rw	-	All	0 ~ 8	-
	01h	Mapping entry 1	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-

Index	Sub-Index	Name	Data type	Access	PDO	Op Mode	Valid value	Unit
	02h	Mapping entry 2	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	03h	Mapping entry 3	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	04h	Mapping entry 4	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	05h	Mapping entry 5	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	06h	Mapping entry 6	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	07h	Mapping entry 7	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
	08h	Mapping entry 8	U32	rw	-	All	0x0 ~ 0xFFFFFFFF	-
1C00h	-	Sync manager communication type	-	-	-	-	-	-
	00h	Number of entries	U8	ro	-	All	4	-
	01h	Communication type sync manager 0	U8	ro	-	All	1	-
	02h	Communication type sync manager 1	U8	ro	-	All	2	-
	03h	Communication type sync manager 2	U8	ro	-	All	3	-
	04h	Communication type sync manager 3	U8	ro	-	All	4	-
1C12h	-	Sync manager 2 PDO assignment	-	-	-	-	-	-
	00h	Number of assigned PDOs	U8	rw	-	All	0 ~ 1	-
	01h	Index of assigned RxPDO 1	U16	rw	-	All	0x1600 ~ 0x1603	-
1C13h	-	Sync manager 3 PDO assignment	-	-	-	-	-	-
	00h	Number of assigned PDOs	U8	rw	-	All	0 ~ 1	-
	01h	Index of assigned TxPDO 1	U16	rw	-	All	0x1A00 ~ 0x1A03	-
1C32h	-	Sync manager 2 synchronization	-	-	-	-	-	-
	00h	Number of synchronization parameters	U8	ro	-	All	12	-
	01h	Synchronization type	U16	ro	-	All	0 ~ 2	-
	02h	Cycle time	U32	ro	-	All	250000 ~ 4000000	ns
	04h	Synchronization types supported	U16	ro	-	All	5	-
	05h	Minimum cycle time	U32	ro	-	All	187500	ns
	06h	Calc and copy time	U32	ro	-	All	31250	ns
	09h	Delay time	U32	ro	-	All	31250	ns
	0Ch	Cycle time too small	U16	to	-	All	0	-
1C33h	-	Sync manager 3 synchronization	-	-	-	-	-	-
	00h	Number of synchronization parameters	U8	ro	-	All	10	-
	01h	Synchronization type	U16	ro	-	All	0 ~ 2	-
	02h	Cycle time	U32	ro	-	All	250000 ~ 4000000	ns
	04h	Synchronization types supported	U16	ro	-	All	5	-
	05h	Minimum cycle time	U32	ro	-	All	187500	ns
	06h	Calc and copy time	U32	ro	-	All	31250	ns
	09h	Delay time	U32	ro	-	All	-	ns
	0Ch	Cycle time too small	U16	ro	-	All	0	-
603Fh	00h	Error code	U16	ro	Y	All	0x0 ~ 0xFFFF	-
6040h	00h	Controlword	U16	rw	Y	All	0x0 ~ 0xFFFF	-
6041h	00h	Statusword	U16	ro	Y	All	0x0 ~ 0xFFFF	-
605Ah	00h	Quick stop option code	I16	rw	-	All	2	-
605Bh	00h	Shutdown option code	I16	rw	-	All	0	-
605Ch	00h	Disable operation code	I16	rw	-	All	0	-
605Dh	00h	Halt option code	I16	rw	-	pp pv tq hm	2	-



Index	Sub-Index	Name	Data type	Access	PDO	Op Mode	Valid value	Unit
605Eh	00h	Fault reaction option code	I16	rw	-	All	0 ~ 2	-
6060h	00h	Modes of operation	I8	rw	Y	All	0 ~ 10	-
6061h	00h	Modes of operation display	I8	ro	Y	All	0 ~ 10	-
6062h	00h	Position demand value	I32	ro	Y	pp hm csp	-2147483648 ~ 2147483647	inc
6063h	00h	Position actual internal value	I32	ro	Y	All	-2147483648 ~ 2147483647	count
6064h	00h	Position actual value	I32	ro	Y	All	-2147483648 ~ 2147483647	inc
6065h	00h	Following error window	U32	rw	Y	pp csp	0 ~ 4294967295	inc
6066h	00h	Following error time out	U16	rw	Y	pp csp	0 ~ 65535	ms
6067h	00h	Position window	U32	rw	Y	pp	0 ~ 4294967295	inc
6068h	00h	Position window time	U16	rw	Y	pp	0 ~ 65535	ms
606Bh	00h	Velocity demand value	I32	ro	Y	pv csv	-2147483648 ~ 2147483647	inc/s
606Ch	00h	Velocity actual value	I32	ro	Y	All	-2147483648 ~ 2147483647	inc/s
606Dh	00h	Velocity window	U16	rw	Y	pv	0 ~ 65535	inc/s
606Eh	00h	Velocity window time	U16	rw	Y	pv	0 ~ 65535	ms
6071h	00h	Target torque	I16	rw	Y	tq cst	-32768 ~ 32767	0.1%
6072h	00h	Max torque	U16	rw	Y	All	0 ~ 65535	0.1%
6074h	00h	Torque demand	I16	ro	Y	All	-32768 ~ 32767	0.1%
6075h	00h	Motor rated current	U32	ro	-	All	0 ~ 4294967295	mA
6076h	00h	Motor rated torque	U32	ro	-	All	0 ~ 4294967295	mNm
6077h	00h	Torque actual value	I16	ro	Y	All	-32768 ~ 32767	0.1%
607Ah	00h	Target position	I32	rw	Y	pp csp	-2147483648 ~ 2147483647	inc
607Ch	00h	Home offset	I32	rw	Y	All	-2147483648 ~ 2147483647	inc
607Dh	-	Software position limit	-	-	-	-	-	-
	00h	Number of entries	U8	ro	-	pp csp	2	-
	01h	Min position limit	I32	rw	Y		-2147483648 ~ 2147483647	inc
	02h	Max position limit	I32	rw	Y		-2147483648 ~ 2147483647	inc
607Fh	00h	Max profile velocity	U32	rw	Y	pp pv hm	0 ~ 4294967295	inc/s
6081h	00h	Profile velocity	U32	rw	Y	pp	0 ~ 4294967295	inc/s
6083h	00h	Profile acceleration	U32	rw	Y	pp pv	0 ~ 4294967295	inc/s <sup>2</sup>
6084h	00h	Profile deceleration	U32	rw	Y	pp pv	0 ~ 4294967295	inc/s <sup>2</sup>
6085h	00h	Quick stop deceleration	U32	rw	Y	pp pv hm csp csv	0 ~ 4294967295	inc/s <sup>2</sup>
6087h	00h	Torque slope	U32	rw	Y	tq	0 ~ 4294967295	0.1%/s
6098h	00h	Homing method	I8	rw	Y	hm	-128 ~ 127	-
6099h	-	Homing speeds	-	-	-	-	-	-
	00h	Number of entries	U8	ro	-	hm	2	-
	01h	Speed during search for switch	U32	rw	Y		0 ~ 4294967295	inc/s
	02h	Speed during search for zero	U32	rw	Y		0 ~ 4294967295	inc/s

Index	Sub-Index	Name	Data type	Access	PDO	Op Mode	Valid value	Unit
609Ah	00h	Homing acceleration	U32	rw	Y	hm	0 ~ 4294967295	inc/s <sup>2</sup>
60B1h	00h	Velocity offset	I32	rw	Y	pp pv hm csp csv	-2147483648 ~ 2147483647	inc/s
60B2h	00h	Torque offset	I16	rw	Y	All	-32768 ~ 32767	0.1%
60B8h	00h	Touch probe function	U16	rw	Y	All	0 ~ 65535	-
60B9h	00h	Touch probe status	U16	ro	Y	All	0 ~ 65535	-
60BAh	00h	Touch probe 1 positive edge	I32	ro	Y	All	-2147483648 ~ 2147483647	inc
60BBh	00h	Touch probe 1 negative edge	I32	ro	Y	All	-2147483648 ~ 2147483647	inc
60BCh	00h	Touch probe 2 positive edge	I32	ro	Y	All	-2147483648 ~ 2147483647	inc
60C2h	-	Interpolation time period	-	-	-	-	-	-
	00h	Number of entries	U8	ro	-	csp csv cst	2	-
	01h	Interpolation time period value	U8	rw	-		0 ~ 255	-
	02h	Interpolation time index	I8	rw	-		-128 ~ 63	-
60C5h	00h	Max acceleration	U32	rw	Y	pp hm pv	0 ~ 4294967295	inc/s <sup>2</sup>
60C6h	00h	Max deceleration	U32	rw	Y	pp hm pv	0 ~ 4294967295	inc/s <sup>2</sup>
60E0h	00h	Positive torque limit value	U16	rw	Y	All	0 ~ 65535	0.1%
60E1h	00h	Negative torque limit value	U16	rw	Y	All	0 ~ 65535	0.1%
60F4h	00h	Following error actual value	I32	ro	Y	pp hm csp	-2147483648 ~ 2147483647	inc
60FCh	00h	Position demand internal value	I32	ro	Y	pp hm csp	-2147483648 ~ 2147483647	count
60FDh	00h	Digital inputs	U32	ro	Y	All	0x0 ~ 0xFFFFFFFF	-
60FEh	-	Digital outputs	-	-	-	-	-	-
	00h	Number of entries	U8	ro	-	All	2	-
	01h	Physical outputs	U32	rw	Y		0x0 ~ 0xFFFFFFFF	-
	02h	Bit mask	U32	rw	Y		0x0 ~ 0xFFFFFFFF	-
60FFh	00h	Target velocity	I32	rw	Y	pv csv	-2147483648 ~ 2147483647	inc/s
6502h	00h	Supported drive modes	U32	ro	-	All	0x0 ~ 0xFFFFFFFF	-